Tempas Script Language

Tempas has a built in scripting C like scripting language with some C++ like member functions. Since many users of Tempas might be familiar with Digital Micrograph (DM) by Gatan Inc., there has been an effort made to make much of the scripting functionality of DM available in Tempas. Thus while many functionalities have alternate function names and arguments, in most cases there will be a DM syntax compatible function available. This is so that many DM scripts can be directly translated to Tempas with minimal effort. There is a basic difference in the syntax between DM and MT scripting when subroutines are used, but the difference is rather trivial and is explained below.

When using subroutines, the main entry point must have the routine main() declared as in

```
main() {
  number x = 10
  number y = 5
  number z = test(x,y)
  print(z)
}
int test(number x, number y) {
  return (x + y)
}
```

If there are no function / subroutine calls, then one can use either

```
main() {
  number x = 10
  number y = 5
  number z = x + y
  print(z)
}
```

or simply

```
number x = 10

number y = 5

number z = x + y

print(z)
```

without the main() { } declaration

This document parallels the DM scripting documentation such that differences and compatible syntax are clearly described.

There are some major differences between the scripting in DM and MT as far as the support of HRTEM simulation is concerned. MT allows the user to script the simulation.

At this point not all aspects of the simulation can be controlled, but this will change with further development. Functions marked with an * are DM functions that are not (yet) implemented in Tempas.

EXECUTING THE SCRIPT: Execution of the script is done by pressing the "Enter" key when the Script window has keyboard focus. This is fn+Return on a MacBook or MacBook Pro. While the above is still true, the Script Window has now gained a "Run" button which starts the script. The "Run" button changes to a "Stop" button when the script is running.

Language Syntax

The Tempas scripting language is very similar to the syntax of the "C" programming language. The language is fairly simple, but is still quite powerful as in that it supports such types as "Image", "ImageStack", "Microscope"... and so on as built in types. In many respects the types correspond to the type "Class" as used in C++ as they have built in "member functions" that operate on the type.

The language is case insensitive such that number, Number, Number etc. are all interpreted as the lower case type number

Types

int, short or bool : Integer number Number, float : Real number

Complex Number or Cmplx : Complex number {x,y}

String : Holds a string like "This is a String"
Image : a 2D Image, Height (or)Width can be 1

ComplexImage : a Complex Image of the above

Image3D : a 3D Volume "Image" of (width,height,depth)

ComplexImage3D : a Complex Image3D of the above
ImageStack : a "stack" of Images of any number
Simulation : an instance of a "Simulation"
Microscope : an instance of a "Microscope"

Vector : a Vector of real or complex numbers

Matrix : a Matrix (ncols, nrows) of real or complex numbers

File : a "File" that can be written to

The language allows the use of the following type names

short int

"bool", "short" and "int" are all Integers (int) while the type "number" is a real number (float). The built in constants "True", "False", "Yes", "No", "On" and "Off" (not case sensitive) correspond to the numbers 1 and 0 respectively. The constant π can be

expressed either as just "Pi" or as a function pi(). The constant "e" is expressed as a function exp(..).

Comments at the end of lines are specified using "//"

```
Multiple lines comments can be started and ended by a pair of /* and */
Take must be taken to not have other such pairs within the outer set.

Example
/*
number i
Image testImage = NewImage(512,512)
Image anotherImage(512,512,sin(2*pi*icol/128)+cos(2*pi*irow/64))
```

The three lines in the middle will be ignored as if they were not present.

Arrays

The scripting language supports arrays of Types Hence one can write

```
number x[100]Declares x to hold 100 numbers. Each element is indexed as x[i]Image img[5]Declares 5 "Pointers" to Images. Each Image must be created separately, using NewImage or something similarString str[40]Declares 40 empty strings
```

The syntax allows

```
x[0] = 5
x[1] = x[0]
int i
number \ x[100], y
image \ img[2], img2
for(int i=0; i < 100; i++) \ x[i] = sin(2*pi*i/64)
img[0] = NewImage("name",512,512)
img[1] = img[0]
str[0] = "Hello \ there"
str[1] = str[0]
y = img2[3,5] // y \ is \ assigned \ the \ value \ of \ the \ pixel \ at \ position \ [3,5]
y = img[1].getpixel(3,5)
and so on.
```

Control loops key words

```
for, do, while, continue, break
```

```
Examples. for:
               // Declares the two variables x and y
number x,y
number a = 10.2, b = -3.5 // Declares a and b and sets a to 10.2 and b to -3.5
______
// Initializes x to 0, executes the loop as long as x is less than 10
// and at the end of the loop increments x with 1
// The syntax x++ is equivalent to x = x + 1
______
for (x = 0; x < 10; x++) {
     y = a*x + b // Defines a line segment
}
// Alternatively one could have done something like this
// Statements between /* ... */ are not executed. Treated as comments
number x[10], y[10]
for ( int i = 0; i < 10; i++) {
     /* y = slope * x + intercept */
     y[i] = a*x[i] + b
}
// or
for (x = 0; x < 10;) {
                        \ensuremath{//} here x is incremented after evaluating the
     y = a*(x++) + b
expression
     // y = a^*(++x) + b; here x is incremented before evaluating the
expression
}
do and while:
number x[10],y[10] // Declares the two arrays x and y of real numbers
number a = 10.2, b = -3.5 // Declares a and b and sets a to 10.2 and b to -3.5
int i = 0
do {
     y[i] = a*x[i] + b // Defines a line segment
     i++
} while (i < 10)
while:
number x[10],y[10] // Declares the two arrays x and y of real numbers
number a = 10.2, b = -3.5 // Declares a and b and sets a to 10.2 and b to -3.5
int i = 0
while (i < 10) {
     y[i] = a*x[i] + b // Defines a line segment
}
```

Library Functions

Library functions are a number of predefined functions that operate on numbers, strings and images and image-volumes(Image3D).

Library functions operating on image]/image3D usually take the image(3D) of interest as an argument and returns an instance of the "result", leaving the argument unchanged.

An example of the use of a predefined function is FFT. The function takes an image as an argument and returns the Fourier Transform of the argument as a new image. Usage could be

Member Functions

Member functions are functions that operate on an instance of a variable type. An example of this would be the various functions that belong to the variable type "Image". The member functions operate directly on "itself". Thus while many library return a new image resulting from an operation on a copy of its argument, the member function will change itself and return nothing (except when specifically noted). Thus if one wanted to take the Fourier transform of an image using a member function, this would be

```
img.fft()  // Take the Fourier Transform of itself
img.rotate(45)  // Rotate oneself 45 degrees anti-clockwise
```

Built-in Implied loop keywords (follows the use in DM and clearly inspired by DM)

```
// The index of the column in an implicit loop over entire image
icol
irow
               // The index of the row in an implicit loop over entire image
               // The value of the radius in an implicit loop over entire image
iradius
               // The value of the angle in an implicit loop over entire image
itheta
               // The index of the plane in an implicit loop over entire image3D
iplane
iwidth
               // The width of the image while within an implied loop
               // The height of the image while within an implied loop
iheight
idepth
               // The depth of the image while within an implied loop
ipoint
               // The number of points of the image while within an implied loop
```

The built in loop key words are incredibly powerful and save an enormous amount of computing time. They should always be used whenever possible.

Whenever one wants to do a loop over the entire image such as

and "Some Expression" can be expressed in terms of icol, irow, iradius etc.. , one should use these implied loops.

For instance the Expression

```
img = sin(2*pi*icol/32) + sin(2*pi*irow/32)
```

Is equivalent to evaluating the following.

```
number i,j,x,y
number width = img.GetWidth()
number height = img.GetHeight()
for (j = 0; j < height; j++) {
    y = sin(2*pi*j/32)
    for (i = 0; i < width ; i++) {
        x = sin(2*pi*i/32)
        img[i,j] = x+y
        // or one could write
        // SetPixel(img,i,j,x+y)
        // img.SetPixel(i,j,x+y)</pre>
```

```
}
}
Similarly
img = exp(-iradius*iradius/64) or img = exp(-iradius**2/64)
Is equivalent to
number i,j,x,y,val
number width = img.GetWidth()
number height = img.GetHeight()
for (j = 0; j < height; j++) {
      y = j - height/2
      for (i = 0; i < width; i++) {
             x = i - width/2
             val = exp(-(x**2+y**2)/64) // iradius = sqrt(x*x+y*y)
             SetPixel(img,i,j,val)
      }
}
```

The first expressions take a fraction of a second to compute, while the second approach can take minutes. Thus you should always use the expressions **icol** and **irow** whenever possible when you want to do a loop over the entire image pixel by pixel. It will be possible if the pixel value at (i,j) is an expression of i and j (**icol** and **irow**). The power of the use of **icol** and **irow** cannot be overestimated. When using the type Image3D, **iplane** takes on the third dimension (z)

```
Image3D vol(32,32,32,iplane) // Creates an image-volume of size 32*32*32 //where each "plane" in the z-dimension is // set to the value of its z- index (\emptyset - 31)
```

Graphing Options


1 Dimensional data can be visualized using the functions

```
graphxy(...)
plot(...)
```

and implicitly by displaying Images 1D (default) or 2D (setting the display style)

```
The code.....
```

```
Image sineWave(512,1,sin(2*pi*icol/128))
sineWave.show()
...
will result in the following output
```




```
The same output could be produced by
.....

number y[512]

for(int i =0; i < 512; i++) {
    y[i] = sin(2*pi*i/128)
}

plot(y)
.....

An example of plotting y vs x is the following...
```



Right Clicking in the Graph Window brings up a window for setting some further display options

```
Graph Window Style

Graph Number 1

Min

Max

X-Axis 0l

511

Y-Axis -1.1

Draw Grid Fill/Line Color

Opacity 100 %

Graph Style


Points
Points - Line
Line
Filled + Line
Filled - Filled

Fill / Bar Style


Solid Fill
Columns 40 % Width between point
```

```
int i
for(i = 0; i < 512; i++) {
      x[i] = 2*i
      y[i] = exp(-(x[i]/2-256)**2/sigma**2)
plot (x,y)
and...
number y[512], x, sigma=30
int ndx,i
for(i = 0; i < 10000; i++) {
      x = GaussianRandom(sigma)
      ndx = x + 256
      if (ndx < 0) continue
      if (ndx > 511) continue
      y[ndx]++
graphxy (y)
and....
Image y(512,4)
number x[4]
for(int i = 0; i < 512; i++) {
       for(int j=0; j < 4; j++) {
             x[j] = sin(2*pi*i/
((j+1)*128))
             y[i,j] = x[j]
```

number x[512], y[512], sigma = 40



```
}
y.setName("Sine-Waves")
// 1 = rasterimage, 2 = RGB, 3 = SurfacePlot,
// 4 = Lineplot, 5 = Table, 6 = ArgandPlot,
// 7 = ComplexLinePlot
y.setDisplayType(4)
y.show()
```



Scripting Reference

Real Numbers / Integer Numbers

Declaration

```
number x number x(3.4) Declares x and sets it to the value 3.4 int ix Declares ix and sets it to the int ix(3.4) the value 3
```

Operators (operating on numbers), read Integer when appropriate

Name	Summary
!	Logical NOT operator for a
	real number
! =	Inequality operator for real
	numbers
& &	Logical AND operator for real
	numbers
*	Multiply operator for real
	numbers
* *	Exponentiation operator for
	real numbers
*=	Multiply and assign operator
	for real numbers
+	Addition operator for real
	numbers
++	Increment operator for a real
	number
+=	Add and assign operator for
	real numbers
_	Negation operator for a real
	number
_	Subtraction operator for real
	numbers
	Decrement operator for real
	numbers
_=	Subtract and assign operator
	for real numbers

/ /=	Division operator for real numbers Divide and assign operator for real number
<	Less than operator for real numbers
<=	Less than or equal operator for real numbers
=	Assignment operator for real numbers
==	Equality operator for real numbers
>	Greater than operator for real numbers
>=	Greater than or equal operator for real numbers
?	Arithmetic if operator for real numbers
H	Logical OR operator for real numbers

Functions (operating on numbers)

Name	Summary
abs	Calculates absolute value of a real number
acos	Calculates the arccosine of a real number
acosh	Calculates the hyperbolic arccosine of a real number
AiryAi	Calculates the Airy Ai function
AiryBi	Calculates the Airy Bi function
asin	Calculates the arcsine of a real number
asinh	Calculates the hyperbolic arcsine of a real number
atan	Calculates the arctangent of a real number
atan2	Calculates the arctangent of y/x for real numbers, real
atanh	images or a complex image Calculates the hyperbolic
BesselI	arctangent of a real number Calculates the general Bessel

I function

Calculates the general Bessel BesselJ

J function (0 , 1 and N)

BesselK Calculates the general Bessel

K function

BesselY Calculates the general Bessel

Y function of orders (0,1 and

n)

Calculates the beta function Beta

BinomialCoefficient Calculates the binomial

coefficient ${}_{n}C_{k}$

BinomialRandom* Calculates a random number

with binomial distribution

Clip real number to be in a clip

cos Calculates the cosine of a

real number

Calculates the hyperbolic cosh

cosine of a real number

distance Calculates the pythagorean

theorem

erf Calculates the error function erfc

Calculates the complement of

the error function

exp Calculates the exponential of

a real number

Calculates the exponential exp1

and of a real number and

subtracts 1

exp10 Calculates 10 raised to a

real number

Calculates 2 raised to a real exp2

number

ExponentialRandom Calculates a random number

with exponential distribution

Factorial Calculates the factorial of a

real number

Gamma Calculates the gamma of a

real number

GammaP Calculates the incomplete

gamma function

GammaQ Calculates the complement of

the incomplete gamma function

GammaRandom* Calculates a random number

with gamma distribution

Calculates a random number GaussianRandom

with gaussian distribution
LegendrePolynomial Calculates the Legendre

polynomial function

log Calculates the logarithm of a

real number

log1 Calculates the logarithm of a

real number and adds 1

log10 Calculates the logarithm base

10 of a real number

log2 Calculates the logarithm base

2 of a real number

LogGamma Calculates the log gamma of a

real number

max Calculates the maximum of two

real numbers

Maximum Calculates the maximum of a

Median

Round

given list of real numbers
Calculates the median of a
given list of real numbers

min Calculates the minimum of two

real numbers

Minimum Calculates the minimum of a

given list of real numbers

mod Calculates the integer

modulus for real numbers

Pi Returns an approximation of π

PoissonRandom Calculates a random number with poisson distribution

Random Calculates a random number

with uniform distribution

Remainder Calculates the integer

remainder for real numbers
Rounds a real number to the

nearest integer

Sqn Calculates the sign of a real

number

sin Calculates the sine of a real

number

sinh Calculates the hyperbolic

sine of a real number

SphericalBesselJ Calculates the spherical

Bessel J function

SphericalBesselY Calculates the spherical

Bessel Y function

sqrt Calculates the square root of

a real number

tan	Calculates the tangent of a
	real number
tanh	Calculates the hyperbolic
	tangent
toDeg	Returns the value of the
	argument(radians) in Degrees
toRad	Returns the value of the
	argument(degrees) in radians
Trunc	Truncates a real number to an
	integer
UniformRandom	Calculates a random number
	with uniform distribution
*Not yet implemented	

Pre Defined Constants

Name	Summary
true	Evaluates to 1
false	Evaluates to 0
yes	Evaluates to 1
no	Evaluates to 0
on	Evaluates to 1
off	Evaluates to 0
pi	Evaluates to "pi" = 3.14

Complex Numbers

Declaration

complexnumber z	Declares a complex number variable z set to (0,0)
cmplx z	cmplx is equivalent to complexnumber
cmplx z(1.0)	Declares z as a complex number and sets it equal to (1.0 + i0.0)
cmplx z(1.0,0.3)	Declares z as a complex number and sets it equal to

```
(1.0 + i0.3) cmplx z(cis(pi/4)) Declares z as a complex number and sets it equal to \exp(i*pi/4) \ (\cos(pi/4) + i*\sin(pi/4))
```

Operators

Name	Summary
!=	Inequality operator for
•-	complex numbers
*	Multiply operator for complex
	numbers
**	Exponentation operator for
	complex numbers
*=	Multiply and assign operator
	for complex numbers
+	Addition operator for complex
	numbers
+=	Add and assign operator for
	complex numbers
-	Negation operator for a
	complex number
_	Subtraction operator for
	complex numbers
_=	Subtract and assign operator
	for complex numbers
/	Division operator for complex
	numbers
/=	Divide and assign operator
	for complex numbers
=	Assignment operator for
	complex numbers
==	Equality operator for complex
	numbers
?	Arithmetic operator for
	complex numbers

Functions

Name	Summary
abs()	Calculates the absolute value of a complex number

cis()	<pre>Calculates a unit vector in the complex plane cis(arg) =</pre>
	(cos(arg), sin(arg))
complex()	Creates a complex number from
	two real numbers
<pre>conjugate()</pre>	Calculates the conjugate of a
	complex number
cos()	Calculates the cosine of a
	complex number
cosh()	Calculates the hyperbolic
	cosine of a complex number
exp()	Calculates the exponential of
,	a complex number
imaginary()	Returns the imaginary portion
2 ,,	of a complex number as a real
	number
log()	Calculates the logarithm of a
	complex number
modulus()	Calculates the modulus of a
,,	complex number
norm()	Calculates the norm of a
``	complex number
Phase()	Calculates the phase of a
()	complex number
Polar()	Calculates the polar
- 5 - 5 - ()	representation of a
	rectangular complex number
real()	Returns the real portion of a
	complex number
Rect()	Calculates the rectangular
``	representation of a polar
	complex number
sin()	Calculates the sine of a
	complex number
sinh()	Calculates the hyperbolic
	sine of a complex number
sqrt()	Calculates the square root of
	a complex number
tan()	Calculates the tangent of a
• •	complex number
tanh()	Calculates the hyperbolic
• •	tangent of a complex number

Complex Number Member Functions

Functions

Name	Summary
set()	Sets the x,y pair of the complex number
real()	returns the real part of the complex number or sets the value of the real part if an argument is given.
imag()	returns the imaginary part of the complex number or sets the value of the imaginary part if an argument is given.
x()	returns the real part of the complex number or sets the value of the real part if an argument is given.
У()	returns the imaginary part of the complex number or sets the value of the imaginary part if an argument is given.
setX()	Equivalent to x(arg)
setY()	Equivalent to y(arg)
phase()	returns the phase in radians of the complex number
angle()	returns the phase in degrees of the complex number
modulus()	returns the modulus of the complex number
<pre>modsq()</pre>	returns the modulus square of the complex number
conjugate()	returns the complex conjugate of the complex number

Example:

```
ComplexNumber c(2,3)  // Declares and initializes complex c
number x = c.x()  // x = 2
number y = c.y()  // y = 3

c.x(10)  // Sets the real part to 10
c.y(4)  // Sets the imaginary part to 4
c.setX(10)  // Sets the real part to 10
c.setY(4)  // Sets the imaginary part to 4

c.set(4,6)  // Sets the complex number equal to (4,6)

cmplx d = c.conjugate()
```

Real Images

Declaration

image img	Declares a pointer to an image which must be created or assigned
<pre>image img(ncols,nrows)</pre>	Declares and creates a real image of size ncols by nrows Width=ncols , Height=nrows
<pre>image img(512,512,exp(-iradius**2/64))</pre>	
	Declares and creates a real image of size 512 by 512, assigning it to a Gaussian of sigma 8 (exp (- (r/8)**2)

Operators

Name	Summary
*	Multiply operator for real
	images
* *	Exponentiation operator for
	real images
*=	Multiply and assign operator
	for real images
+	Addition operator for real
	images
++	Increment operator for a real
	images
+=	Add and assign operator for
	real images
-	Negation operator for a real
	images
_	Subtraction operator for real
	images
_=	Subtract and assign operator
,	for real images
/	Division operator for real
	images

/=	Divide and assign operator
	for real images
<	Less than operator for real
	images
<=	Less than or equal operator
	for real images
=	Assignment operator for real
	images
==	Equality operator for real
	images
>	Greater than operator for
	real images
>=	Greater than or equal
	operator for real images
?	Arithmetic if operator for
	real images
ſ 1	Image region expression
LJ	-mago rogram omprobbion

Library Functions

lame	Summary
abs	Returns a real image
4.55	containing the absolute
	values of a real image
acos	Returns a real image
	containing the arccosine of a
	real image
acosh	Returns a real image
	containing the hyperbolic
	arccosine of a real image
asin	Returns a real image
	containing the arcsine of a
	real image
asinh	Returns a real image
	containing the hyperbolic
	arcsine of a real image
atanh	Returns a real image
	containing the hyperbolic
	arctangent of a real image
ceiling	Sets all values larger than a
	given value to the given
	value
clip	Sets all values smaller than
	a given value to the value
	and all values larger than a
	given value to the given
	value
cos	Returns a real image
	containing the hyperbolic
	cosine of a real image

cosh Returns a real image

containing the cosine of a

real image

DotProduct Calculates the dot product of

two real image expressions

exp Returns a real image

containing the exponential of

a real image

exp1 Returns a real image

containing the exponential of
a real image and subtracts 1

exp2 Returns a real image

exp10

containing 2**image Returns a real image containing 10**image

ExprSize Sets the physical size of a

real image expression

ExprSize Sets the physical size of a

real image expression

factorial Returns the factorial of an

image (values are rounded to

integers)

floor Sets all values smaller than

a given value to the given

value

log1 Returns an image of the log

of an image after subtracting

1.

log10 Calculates log10 of an image log2 Calculates log2 of an image

log Calculates the natural

logarithm of an image

max Finds the maximum of a real

image expression

max Finds the maximum value and

position for a real image

expression

mean Calculates the mean of a real

image expression

MeanSquare Calculates the mean square of

a real image expression

median Calculates the median of a

real image expression

min Finds the minimum value and

position for a real image

expression

min Finds the minimum of a real

image expression

norm Returns an image of the norms

of an image (xi-squared)

Polynomial Calculates a polynomial

expansion using a real image

expression

Pow Returns a real image

containing image**x
Returns a real image
containing 2**image

pow10 Returns a real image

pow2

sin

containing 10**image

product* Calculates the product of a

real image expression

RMS Calculates the RMS of a real

image expression

Round Rounds all values to the

nearest integer

sum Calculates the sum of a real

image expression

sigma Returns the standard

deviation of an image Returns a real image

containing the sine of a real

image

sinh Returns a real image

containing the hyperbolic sine of a real image

sqrt Returns a real image

containing the square root of

a real image

sq Returns a real image

containing the square of a

real image

square Returns a real image

containing the square of a

real image

stdv Returns the standard

deviation of an image Returns a real image

tan Returns a real image containing the tangent of a

real image

tanh Returns a real image

containing the hyperbolic tangent of a real image

TimeBar" Displays a timebar while

evaluating real image

expression

Trunc Truncates all real values to

the integer part

Variance Returns the variance of the

image

Vectorlength Returns the square root of the sum of all pixels squared

Warp Calculates bilinear

*Not yet implemented

Complex Images

Declaration

compleximage img

Declares a "Pointer" to a complex image which must be created or assigned

compleximage img(ncols, nrows)

Declares and creates a complex image of size ncols by nrows

Width=ncols, Height=nrows

However it is not necessary in most instances to declare an image to be complex. One can also declare it as type Image. The construct...

Operators

Name	Summary
*	Multiply operator for complex images
**	Exponentiation operator for complex images
*=	Multiply and assign operator for complex images
+	Addition operator for complex images
+=	Add and assign operator for complex images

-	Negation operator for a complex images
-	Subtraction operator for
	complex images
_=	Subtract and assign operator
	for complex images
/	Division operator for complex
	images
/=	Divide and assign operator
	for complex images
=	Assignment operator for
	complex images
==	Equality operator for complex
	images
?	Arithmetic if operator for
	complex images

Functions

Name	Summary
ComplexConjugate	Returns the complex conjugate of an image
Conjugate	Returns the complex conjugate of an image
Real	Returns the real part of an image
Imaginary	Returns the imaginary of an image
Intensity	Returns the modulus square of a complex image
Phase	Returns the phase of a complex image
Modulus	Returns the modulus (amplitude) of a complex image

Built in Image Expressions

Summary
When used in an expression involving an image, icol will

irow

iplane

iradius

itheta

iwidth

iheight

column in the image and there is an implied loop over all the elements of an image. Basically each pixel takes the value of the column number of the pixel. When used in an expression involving an image, irow will refer to the index of the row

refer to the index of the row in the image and there is an implied loop over all the elements of an image. Each pixel takes the value of the row number of the pixel. When used in an expression involving a 3D image, iplane will refer to the index of the depth in the 3D image and there is an implied loop over all the elements of an image.

Each voxel has the value of the plane number of the

voxel.

When used in an expression involving an image, iradius will refer to the value of sqrt((I-W/2)* (I-W/2)+(J-H/2)* (J-H/2)), where I and J are the column and row index of the image and W and H are the width and height of the image. There is an implied loop over all the elements of an image. Each pixel has the value of the radius of the pixel.

When used in an expression involving an image, itheta will refer to the value of atan((J-H/2)/(I-W/2)), where I and J are the column and row index of the image and W and H are the width and height of the image. There is an implied loop over all the elements of an image. Each pixel has the value of the angle with the x-axis of the pixel.

When used in an expression involving an image, iwidth will refer to the width of the image. It's a constant. When used in an expression

involving an image, iheight
will refer to the height of
the image. It's a constant.

When used in an expression
involving a 3D volume image,
idepth will refer to the
depth of the image. It's a
constant.

ipoints

When used in an expression
involving an image, ipoints
will refer to the number of
pixels in the image. It's a

constant.

Image Stacks

Declaration

Assignment

Member functions

lame	Summary
AddImage(Image)	Adds an image to a stack
<pre>DeleteImage(Image)</pre>	Deletes an image from a stack
FFT(int num)	Performs a Fourier transform
	on an image on the stack
FFT	Performs a Fourier transform

of every image on the stack
GetImage(int Num) Returns an image from a stack
GetnumberOfImages() returns the number of images

in a stack

IFFT(int num) Performs the inverse Fourier

transform on an image in the

stack

IFFT Performs the inverse Fourier

transform of every image on

the stack

Save(String) Saves an image stack as a MRC

file

Volume Images

Declaration / Creation

Volume / 3D Image

Image3D img3(32,32,32)
Declares and creates an Image

Volume of size 32 by 32 by 32

Image3D img3(32,32,32, $\exp(-iradius**2/8**2)$)

Declares and creates an Image Volume of size 32x32x32 and assigning it to a "spherical

Gaussian" of sigma 8

Assignment

Image3D img3 Defines the 3D Image

img3 = existingImage3D
Sets the Image Volume from an

existing 3D image volume

img3[x1:x2,y1:y2,z1:z2] =

existingImage3D[xx1:xx2,yy1:yy2,zz1:zz2] where

(xx2-xx1) = (x2-x1)(yy2-yy1) = (y2-y1)

(zz2-zz1) = (z2-z1)

Image3D img3 Defines the 3D Image

img3= existingStack Sets the Image Volume from an

existing image stack

Creation

Name	Summary	
exprsize3	Function for creating a 3D	
expisizes	Image Volume	
<pre>Image3D name(width,height,dep</pre>	th) or	
<pre>Image3D name(width,height,dep</pre>	age3D name(width,height,depth,ImageExpression)	
	Creates the 3D Volume and	
	assigns the volume to the	
	image expression	
example:		
image3d img = exprsize3(256,256,256)	// Declares and creates a volume image	
	// set to the initial value 0	
image3d img1 = exprsize3(256,256,256,10)	// Declares and creates a volume image	
	// set to the initial value 10	
image3d vol(256,256,256,exp(-iradius**2/2	20**2))	

Member Functions

Name	Summary

BeginFill()	Starts a fill from projections
Depth()	Returns the depth (z dimension in pixels) of the volume image
Display()	Displays a 3D (volume) image
EndFill()	Ends a fill from projections
FFT()	Performs a 3D Fourier
	<pre>transform of a 3D (volume) image</pre>
FFT2()	Performs a 2D Fourier
	transform of each image
	(plane) of the 3D (volume)
	image
FillFromProjection*()	Filling the volume image from a 2D projection
<pre>GetImage(int z)</pre>	Returns a 2D image from a
	given position (z) in the
	volume image
<pre>GetName()</pre>	Returns the name of the image
<pre>GetSize(w,h,d)</pre>	Returns the width, height and
	depth of the volume image
<pre>GetVoxel(x,y,z)</pre>	Returns the value at position
	(x,y,z)
Height()	Returns the height (y

	dimension in pixels) of the
	volume image
IFFT()	Performs a 3D inverse Fourier
	transform of a 3D (volume)
	image
IFFT2()	Performs a 2D Fourier inverse
	transform of each image
	(plane) of the 3D (volume)
	image
<pre>Imaginary()</pre>	Replaces the volume image
	with its imaginary part
Modulus()	Transforms the image to the
	modulus
Phase()	Transforms the image to the
	phase
Real()	Replaces the volume image
	with its real part
Repeat(nx,ny,nz)	Repeat the volume image
	NX,NY,NZ times
RotateX(angle)	Rotate about x clockwise
RotateY(angle)	Rotate about y clockwise
RotateZ(angle)	Rotate about x clockwise
Save()	Saves the volume image as a MRC file
<pre>SetImage(i,image)</pre>	Sets a 2D image at a given
	position (z) in the volume
	image
<pre>SetName("name")</pre>	Sets the name of the 3D image
SetVoxel(x,y,z,value)	Sets the voxel value at
	position (x,y,z)
sq()	Replaces each pixel (voxel)
	with the square of its value
sqrt()	Replaces each pixel (voxel)
	with the squareroot of its
	value
Width()	Returns the width (x
	dimension in pixels) of the
	volume image
*Not wet implemented	
*Not yet implemented	

Image Data Type

Declaration

image ss
compleximage css

Creating / initializing

Name	Summary
<pre>Exprsize(width,height,)</pre>	Allocates and initializes an image
<pre>realimage(width,height)</pre>	Creates a real image of a given size
<pre>newimage(width,height)</pre>	Creates a real image of a given size
<pre>createimage(width,height)</pre>	Creates a real image of a given size
createfloatimage(width,height	_
<pre>createcompleximage(width,heig</pre>	3
openimage()	opens an existing image file
Example:	
A0 = exprsize(512,512,icol)	Creates an image with label a0 and displays it. The image contains a ramp where each pixel has the value of the column number.
<pre>Image ss = newimage("real ima compleximage css = createcomp</pre>	· , ,
<pre>Example: image ss = openimage("image.t</pre>	if")

Image Member Functions

Functions

Name	Summary
ac	Replaces a real image with
	its autocorrelation
acos	Replaces a real with its
	arccosine
acosh	Replaces a real with its

hyperbolic arccosine AdjustAngle Adjusts the image so that it has an angle of 90 degrees. This is applicable for images returned from a simulation. In this case the image represents a periodic object and the angle of the unit cell may be different from 90 AdjustSampling Adjusts the image so that it has equal sampling in x and y. This is applicable for images returned from a simulation. In this case the image represents a periodic object and the sampling along the a and b axes may be different. Amplitude Replaces a complex with its amplitude AnnularHighpassFilter Applies a high pass filter to an image AnnularLowpassFilter Applies a low pass filter to an image ApplyAnnularMask Applies an annular mask to an image ApplyCircularMask Applies a circular mask to an image ApplyCosineMask Applies a cosine mask to an image ApplyHanningMask Applies a Hanning mask to an image ApplyMasksFromImage Applies masks belonging to a different image onto itself Replaces the image with its asin arcsine asinh Replaces the image with its hyperbolic arcsine atan Replaces the image with its arctan atan2 Replaces the image with its arctan Replaces the image with its atanh hyperbolic arctan Autocorrelate Replaces a real image with its autocorrelation (equivalent to ac) bgs Applies a Background Noise Subtraction Filter on a real image Replaces a complex image with CC

ccd

its complex conjugate

Corrects for CCD detector bad

pixels in a real image Sets all values greater than ceiling maxVal to maxVal CenterOfMass Returns the value of and position of the "Center of Mass" clip Sets all values greater smaller than minVal to minVal and all values greater than maxVal to maxVal ConvertToRealSpaceStorage Changes the data storage to regular real space storage (x,y)ConvertToReciprocalSpaceStorage Sets the storage to that of h,k in reciprocal space. (h=0,k=0) at position (0,0)Complexconjugate Replaces a complex image with its complex conjugate (equivalent to cc) ComplexModulusSq This replaces a complex image with the product of itself and its complex conjugate. It is the complex modulus square. Imaginary part is zero Cmsq Equivalent short for ComplexModulusSq Conjugate Replaces a complex image with its complex conjugate (equivalent to cc) cos Replaces a real with its cosine Replaces a real with its cosh hyperbolic cosine Display Displays the image Displayonlogscale Displays the image on a log scale Takes the exponential of an exp image exp1 Takes the exponential of a real image and subtracts the value 1 exp10 Calculates the 10**image Calculates the 2**image exp2 factorial Takes the factorial of each pixel of an image fft Takes the Fourier transform of an image Fills in a 2D image from 1D Fillfromprojection projections Fliphorizontal Flips an image horizontally (around the vertical axis) Flipvertical Flips an image vertically

(around the horizontal axis)

floor Sets all values smaller than

minVal to minVal

GaussianLowpassFilter Applies a Gaussian low pass

filter

GaussianHighPassFilter Applies a Gaussian high pass

filter

GetCalibration Returns the calibration of

the image

GetCalibrationunit Returns the calibration unit

of the image

GetGamma Returns the angle associated

with the image

GetLattice Returns the lattice (if

defined) for the image

GetName Return the name of the image GetPeaklist Returns the peaklist (if

defined) for the image

GetPixel Returns the pixel value for a

given pixel

GetScale Returns the scale/calibration
GetScaleX Returns the scale/calibration

in X

GetScaleY Returns the scale/calibration

in Y

GetSize Returns the width and height

of the image

HasLattice Returns true(1)/false(0) if a

lattice is defined on an

image

HasPeaklist Returns true(1)/false(0) if a

peak list is defined on an

image

Height Returns the height (in

pixels)

HighpassFilter Applies a highpass filter to

the image

Ifft Replaces a complex image in

reciprocal space with its inverse Fourier transform

Imaginary Replaces a complex with its

imaginary part

Intensity Replaces an image with its

modulus squared

Inverse Sets the Image Values to 1/

Values

Invert Sets the image equal to

-Image

Laplacian Takes the Laplacian of a real

image

Log Takes the natural log of a

real image

Log1 Takes the natural log of a

real image after adding the

value 1

log10 Takes the log10 of a real

image

log2 Takes the log2 of a real

image

Max Returns the maximum of a real

image

Mean Returns the mean of a real

image

Min Returns the minimum of a real

image

Modulus Replaces a complex image with

its modulus

PadWithMean Pads an image with its mean

value to specified dimensions

PadWithZero Pads an image with zero to

specified dimensions

Phase Replaces a complex image with

its phase

pow Replaces the image with

image**factor

pow10 Replaces the image with

10**(image)

pow2 Replaces the image with

2**(image)

Powerspectrum Calculates the Power Spectrum

of an image

Ps Calculates the Power Spectrum

of an image

rccd Corrects for CCD detector bad

pixels in a real image (ccd)

Real Replaces a complex image with

its real part

Removeccddefects Corrects for CCD detector bad

pixels in a real image (ccd)
Repeats an image by tiling

Repeat Repeats an image by

Resize Resizes an image

RMS Returns the RMS value of a

real image

Rotate Rotates the image by a given

angle anti-clockwise

RotateLeft Rotates anti-clockwise an

image by 90 deg.

RotateRight Rotates clockwise an image by

90 deg.

Round Rounds all values to the

nearest integer

SetBlackWhite Sets the black and white

display limits of an image

SetCalibration Sets the calibration of an

image

SetCalibrationUnit Sets the calibration unit of

an image

SetImageSpace Sets the space (real/

reciprocal) of an image SetName Sets the name of an image SetPixel Sets a specified pixel to a given value SetScale Sets the scale of an image Sharpen Applies a Sharpening Filter to a real image Shift Shifts the position (0,0) to a new position (x,y) in the image ShiftCenter Shifts the position (0,0) to the position (W/2,H/2) in the image ShiftOrigin Shifts the position (0,0) to the position (W/2,H/2) in the image show Displays an image sigma Returns the standard deviation of a real image sin Replaces a real image with its sine sinh Replaces a real image with its hyperbolic sine Smooth Applies a Smoothing Filter to a real image sobel Applies a Sobel Filter to a real image Takes the square of an image sq Takes the square root of a sqrt real image square Takes the square of an image stdv Returns the standard deviation of a real image Replaces a real with its tan

tangent tanh Replaces a real with its hyperbolic tangent

Applies a Threshold Filter to thf a real image

Transpose Transposes an image

ThresholdFilter Applies a Threshold Filter to

a real image

Truncates the values to its Trunc

integer part

Update Updates an image

Variance

Returns the variance of the

image

wf Applies a Wiener Filter to a

real image

Width Returns the width (pixels) of

an image

WienerFilter Applies a Wiener Filter to a

real image

Example:

```
image img = exprsize(256,256,icol)
img.sin()
img.fft()
img.setname("test")
img.display()
```

Example:

```
// a# as in a0, a1, a10... are automatically assigned as
// images and are displayed by default
a10 = exprsize(256,256,sin(2*pi()*icol/8)*sin(2*pi()*irow/12))
a11 = a10
a11.fft()
a10.setname("test")
a11.setname("Fourier Transform of test")
a12 = a10[64,64,192,192] // a12 is set to the top,left,bottom,right subregion of a10
```

Image Creation

Functions

Name	Summary
ExprSize	Allocates and initializes an image
RealImage	Creates a real image of a given size
NewImage	Creates a real image of a given size
CreateImage	Creates a real image of a given size
CreateFloatImage	Creates a real image of a given size
CreateComplexImage	Creates a complex image of a given size
OpenImage	opens an existing image file
<pre>Image imag(width,height,)</pre>	Declares and creates an image of specified dimensions and optionally assigns it to an image-expression

Images can also be created and assigned from an array numbers, a vector and a matrix $% \left(1\right) =\left(1\right) +\left(1\right$

```
Matrix m(100,100)

Vector v(100)

number x[100]

...

Image i1,i2,i3

i1 = m // Creates an Image of size(100,100)

i2 = v // Creates an Image of size(100,1)

i3 = x // Creates an Image of size(100,1)
```

The images are filled with the content of m, v and x If the images are already created, they must have the dimensions of m, v and x $\,$

Image Management

Functions

Name	Summary	
cexp	Returns a complex image from	
	<pre>two images x and y (real part = cos(x)) (imaginary part = sin(x))</pre>	
cis	Returns a complex image from two images x and y (real part = cos(x)) (imaginary part =	
	$= \cos(x)$ (imaginary part = $\sin(x)$)	
CloseImage	Closes an existing image	
Complex	Returns a complex image from two images x (real part) and	
	y (imaginary part)	
CreateComplexImage	Creates a complex image of a given size	
CreateFloatImage	Creates a real image of a given size	
CreateImage	Creates a new image of a given type	
CreateImageFromDisplay	Creates an image from the information in a given window	
CreateNewImage	Creates a new image of a given type	
CreateRealImage	Creates a real image of a given size	
CreateTableFromImage	Creates a table from an image	

Delete
DeleteImage
DoesImageExist

Extract

get2dSize

getCalibration

getCalibrationUnit

getCalibrationUnitString

getFrontImage
getHeight

getMagnification

getNamedImage

getNumberedImage

getScale
getSize

getUnitString

getWidth
getZoom

NewImage Open OpenImage OpenWithDialog

PrintImage RealImage Resize saveImage setCalibration

setCalibrationUnit

setMagnification
setName
setScale
setUnitString

setZoom

Deletes an image Deletes an image

Returns true/false if a given

named image exists
Returns an image by

extracting a region of an

existing image

Returns width and height of

an image

Returns the calibration of an

image

Returns the calibration unit

of an image

Returns the calibration unit

of an image

Returns the front image Returns the height of an

image

Returns the zoom factor of an

image

Returns the image with a

given name

Returns the image with a

label A#

Returns the scale of an image Returns the width and height

of an image

Returns the calibration unit

of an image

Returns the width of an image Returns the zoom factor of an

image

Creates a new image
Opens a named image file
Opens a named image file
Opens an image file using a

file selector dialog Prints a given image Creates a real image Resizes an image Saves an image

Sets the calibration of an

image

Sets the calibration unit of

an image

Returns the scale of an image Returns the name of an image Sets the scale of an image Sets the calibration unit of

an image

Sets the zoom factor of an

image

Image Processing

Name	Summary
Ac	Returns the autocorrelation
-	of a real image
Align	Aligns two images
AlignImages	Aligns two images
AlignTwoImages	Aligns two images
AnnularHighPassFilter	Returns a new image of a high
-	pass filtered image
AnnularLowPassFilter	Returns a new image of a low
	pass filtered image
ApplyAnnularMask	Returns an image resulting
	from the application of an
	annular mask to an image
ApplyCircularMask	Returns an image resulting
	from the application of an
	annular mask to an image
ApplyCosineMask	Returns an image resulting
	from the application of a
	circular cosine mask to an
	image
ApplyHanningMask	Returns an image resulting
	from the application of a
	circular hanning mask to an
	image
AutoCorrelate	Returns an image resulting
	from the auto-correlation of
	two images
AutoCorrelation	Returns an image resulting
	from the auto-correlation of
	two images
CC	Returns an image resulting
	from the cross-correlation of
	two images
Convolute	Returns an image resulting
	from the convolution of two
	images
Convolve	Returns an image resulting
	from the convolution of two
	images
Correlate	Returns an image resulting
	from the cross-correlation of
	two images

CrossCorrelate Returns an image resulting

from the cross-correlation of

two images

CrossCorrelation Returns an image resulting

from the cross-correlation of

two images

DotProduct Returns the dot-product

(inner product) of two images

FFT Returns the Fourier

transforms of an image FindPattern Returns the position

dependent cross-correlation coefficient between an image

and a pattern

FlipHorizontal Returns an image resulting

from mirroring an image around the vertical axis

FlipVertical Returns an image resulting from mirroring an image

from mirroring an image around the horizontal axis Returns an image resulting

GaussianHighPassFilter Returns an image resulting from the application of a

Gaussian High Pass filter to

an image

GaussianLowPassFilter Returns an image resulting

from the application of an Gaussian Low Pass filter to

an image

HighPass Returns an image resulting

from the application of a Annular High Pass filter to

an image

HighPassFilter Returns an image resulting

from the application of a Annular High Pass filter to

an image

IFFT Returns the inverse Fourier

Invert

transforms of an image Returns the inverse of an

image

Laplacian Returns the Laplacian of an

image

Lowpass Returns an image resulting

from the application of an Annular Low Pass filter to an

image

LowpassFilter Returns an image resulting

from the application of an Annular Low Pass filter to an

image

Negate Returns the inverse of an

image

PhaseCorrelate Returns the phase correlation

between two images

PhaseCorrelation Returns the phase correlation

between two images

PowerSpectrum Returns the Power Spectrum of

an image

Ps Returns the Power Spectrum of

an image

RadialAverage Returns the radial average of

an image

RealFFT Returns the Fourier

Rotate

transforms of an image

RemoveCCDdefects Returns an image by adjusting

for ccd defects of a recorded

image

Repeat Returns an image by repeating

> in x and y an existing image Returns an image resulting

from rotating an image x degrees anti-clockwise

Returns an image resulting RotateLeft

from rotating an image 90

deg. Anti-clockwise

RotateRight Returns an image resulting

from rotating an image 90

deq. clockwise

Scale Returns an image resulting

from scaling an image

Returns an image resulting Sharpen

from applying a sharpening

operation to an image

Shift Returns an image resulting

from shifting the origin of

an exiting image

Returns an image resulting ShiftCenter

from shifting the origin of

an exiting image

ShiftOrigin Returns an image resulting

from shifting the origin of

an exiting image

Smooth Returns an image resulting

> from applying a smoothing operation to an image

Sobel Returns an image resulting

from applying a Sobel operation to an image

Returns the position TemplateMatch

> dependent cross-correlation coefficient between an image

and a pattern

Wf Returns an image resulting

from applying a Wiener Filter

to an image

WienerFilter Returns an image resulting

from applying a Wiener Filter

to an image

Image Data Access

Functions

Name	Summary
GetPixel	Gets the pixel value for a given pixel
GetPixelAmplitude	Gets the pixel amplitude for a given pixel in a complex image
GetPixelPhase	Gets the pixel phase for a given pixel in a complex image
SetPixel	Sets the pixel value for a given pixel
SetPixelAmplitude	Sets the pixel amplitude for a given pixel in a complex image
SetPixelPhase	Sets the pixel phase for a given pixel in a complex image
<pre>[col,row] Image dmg(256,256)</pre>	Indexing into an Image pixel
img[10,10] = value	Sets the pixel at [10,10] to value

Peak Determination

Name	Summary
AddPeakList	Add a peaklist to an image. The peaklist gets merged with any other peaklists for the image.
CreateVectorMap	Creates a vector map from two images (displacements)

FindMaxima	Finds the maxima in an image
FindMinima	Finds the minima in an image
FindPeaks	Finds the peaks in an image
FitDoublePeaks	Fits a peak list to a set of
	overlapping Gaussian peaks
	(two peaks are close)
FitExponentials	Fits the peaks in a peak list
-	to Exponential peaks.
FitGaussians	Fits the peaks in a peak list
	to Gaussian peaks.
FitParabolas	Fits the peaks in a peak list
	to Parabolic peaks.
FitPeaks	Fits the peaks in a peak list
	to Gaussian peaks (other
	shapes available)
GetPeakList	Returns the peak list defined
	for an image
HasPeakList	Return true/false if the
	image has/has not an
	associated peak list
ReadPeakList	Returns a peaklist (image)
	from a peak list file (tab-
	delimited text file)
SavePeaks	Save the peaks in a peak list
	to a file.
SavePeaksWithDialog	Save the peaks in a peak list
-	to a file
SetPeakList	Creates a peaklist for an
	image replacing any existing
	peaklist.
VectorMap	Creates a vector map from two
-	sets of displacements
	L

Lattice Determination

Name	Summary
FitLattice	Fits an existing lattice to a Peaklist
GetLattice	Gets the lattice defined on an image
HasLattice	Return true/false if the image has/has not a lattice defined

Vector

Operators

Declaration

Vector v

Declares a vector, not yet created and assigned

Vector c(10)

Declares and creates a vector of size 10 (10 elements) initialized to 0

ComplexVector v

Declares a complex vector, not yet created and assigned

ComplexVector c(10)

Declares and creates a complex vector of size 10 (10 elements) initialized to (0,0)

Member functions

Summary

angle()	Replaces each element of the
	complex vector with the angle
	(atan2(y/x)) in degrees
at(i)	Returns the value of the
	element of the vector at the
	position 'i'

conjugate() Replaces the complex vector with its complex conjugate Creates the vector of size create(len) imag() Replaces the complex vector with the imaginary component length() Returns the Square root of the sum of the squares modulus() Replaces the complex vector with a real vector containing the modulus of the complex elements modsq() Replaces the complex vector with a real vector containing the modulus square of the complex elements Phase() Replaces each element of the complex vector with the angle (atan(y/x)) in radians Print() Prints out all the values of the vector Replaces the complex vector Real() with a real vector containing the real part of the complex elements Resize(len) Resizes the vector to 'len' number of elements Set(ndx, value) Sets the element of the vector at index 'ndx' to the value 'value' Size() Returns the number of elements in the vector Sorts the vector in Sort(order=0) ascending(0) (default) or descending(1) order Creating an Image from a Vector Vector V(100) Image imag = VCreates an Image of size V.size(),1

Image Display

Name	Summary
------	---------

Display	Shows/Displays an image
DisplayAsTable	Displays the image as a table of numbers
DisplayAt	Displays the image in a window at the given position
DisplayOnLogscale	Displays the image on a log scale
GetSurveyMode	Gets the method of survey technique for setting black and white values
GetSurveyTechnique	Gets the method of survey technique for setting black and white values
GetWindowPosition	Returns the window position of an image
GetWindowSize	Returns the window size for a displayed image
SetDisplayType	Sets the type of display for an image
SetSurveyMode	Sets the method of survey technique for setting black and white values
SetSurveyTechnique	Sets the method of survey technique for setting black and white values
SetWindowPosition	Sets the window position of an image
SetWindowSize	Sets the window size for a displayed image
Show	Equivalent to Display
ShowImage	Equivalent to Display
UpdateImage	Updates the display for a modified image

Image Selections

Name	Summary
ExpandSelection GetSelection	Expands a given selection Gets the rectangle of the

Annotations

Name	Summary
AnnotationType	Returns the type of a given
	annotation
CountAnnotations	Returns the number of
	annotations on the image
CreateArrowAnnotation	Creates an arrow annotation
CreateBoxAnnotation	Creates a rectangular
	annotation
CreateDoubleArrowAnnotation	Creates a double arrow
	annotation
CreateLineAnnotation	Creates a line annotation
CreateOvalAnnotation	Creates an oval annotation
CreateTextAnnotation	Creates an text annotation
DeleteAnnotation	Deletes a given annotation
DeselectAnnotation	Deselects an annotation
GetAnnotationRect	Gets the bounding rectangle
	of a given annotation
GetNthAnnotationID	Gets the ID of an annotation
IsAnnotationSelected	Determines if an annotation
	is selected
MoveAnnotation	Moves the annotation to a
	given position
OffsetAnnotation	Offsets the annotation with
	specified integer offsets
SelectAnnotation	Selects the specified
	annotation
SetAnnotationBackground*	Sets the background of an
	annotation
SetAnnotationColor	Sets the Color of an
	annotation
SetAnnotationFace*	Sets the text face of an
	annotation
SetAnnotationFont	Sets the text font of an
	annotation
SetAnnotationJustification*	Sets the text justification
	of an annotation
SetAnnotationRect	Sets the bounding rectangle

	or an annotation
SetAnnotationSize	Sets the size of an
	annotation
ShiftAnnotation	Shifts the position of an
	annotation. Equivalent to
	MoveAnnotation
ValidAnnotation	Is the annotation valid
*Not yet implemented	

Strings

Operators

Name	Summary
!=	Inequality operator for strings
+	Concatenate a string and a real number
+	Concatenate a string and a complex number
+	Concatenate a complex number and a string
+	Concatenate a real number and a string
+	Concatenate a string and a string
==	Equality operator for strings

Name	Summary
Asc*	Returns numeric value in ascii
Chr*	Returns ascii equivalent of a number as a string
Left*	Returns the leftmost portion of a string
Len*	Returns the length of a string
mid*	Returns the middle portion of a string
right*	Returns the rightmost portion of a string

*Not yet implemented

*Not yet implemented

Persistent Notes (mostly not implemented)

ame	Summary
DeletePersistentNote*	Deletes persistent note
GetPersistentComplexNumberNo	te Gets the value of a
	persistent complex number
	note
GetPersistentNoteState*	Gets persistent note state
GetPersistentNumberNote	Gets the value of a
	persistent number note
GetPersistentRectNote	Gets the value of a
	persistent rect note
GetPersistentRGBNumberNote*	Gets the value of a
	persistent RGB number note
<pre>GetPersistentStringNote*</pre>	Gets the value of a
	persistent string note
<pre>GetPersistentStringNote*</pre>	Gets the value of a
	persistent string note
SetPersistentComplexNumberNo	te Sets the value of a
	persistent complex number
	note
SetPersistentKeywordNote*	Adds a persistent keyword
	note
SetPersistentNoteState*	Sets persistent note state
SetPersistentNumberNote	Sets the value of a
	persistent number note
SetPersistentRectNote	Sets the value of a
	persistent rect note
SetPersistentRGBNumberNote*	Sets the value of a
	persistent RGB number note
SetPersistentStringNote*	Sets the value of a
	persistent string note

Number Conversions

to an
ring
co an
ring with a
to a binary
ed length
o a binary
o a decimal
co a decimal
ed length
co a hex
ed length
co a hex
o an octal
ed length
o an octal
t f t

Dialogs

Name	Summary
ContinueCancelDialog	Puts up a dialog with the option to cancel or continue the script
ErrorDialog	Puts up a dialog with an error string
GetNumber	Prompts for a number to input
GetTwoImages	Prompts for two images to select
GetTwoImagesWithPrompt	Prompts for two images to

	select
OkCancelDialog	Puts up a dialog with the
	option to cancel or continue
	the script
OkDialog	Puts up a dialog with the
	option to accept or not a
	choice
TwoButtonDialog	Puts up a dialog with two
	buttons to choose from

Input/Output

Name	Summary
OpenLogWindow	Opens the log/output window for scripts
OpenResultsWindow	Opens the log/output window for scripts (for DM compatibility)
Print	Prints (writes) an expression to the output window. By default adds a new line character at the end
Result	Prints (writes) an expression to the output window. DM compatible

Movies

Name	Summary
AddImageToMovie	Adds an image to a movie
AddWindowToMovie	Adds a window (containing an image) to a movie
CloseMovie	Closes the movie
CreateNewMovie	Creates a new movie with a given name

Example:

image img = exprsize(256,256,icol)

```
number i
createnewmovie("movie")
for(i=0; i < 256; i++) {
         addimagetomovie(img)
         img.shift(1,0);
}
closemovie()</pre>
```

Miscellaneous

Name	Summary
Catch	catch an exception thrown
Caccii	after a <i>try</i> statement
CloseProgressWindow*	Not Yet Implemented
CommandDown	Returns true/false depending on if the Command (Apple) key is down or not
DateStamp	Not Yet Implemented
Delay	Delay execution of the script x number of 1/60th of a second
DoEvents	Checks for input from the keyboard
Exit	Exit from the script
GetKey	Returns the key currently pressed
Help	Gets help on a given function
OpenAndSetProgressWindow*	Not Yet Implemented
OptionDown	Returns true/false depending on if the Option key is down or not
ShiftDown	Returns true/false depending on if the Shift key is down or not
SpaceDown	Returns true/false depending on if the Space bar is down or not
Throw	Throw an exception
ThrowString	Throw an exception with a string
Try	Try to execute the following bracketed statements. Check for an exception by using the catch statement
*Not yet implemented	

Electron Microscopy Simulation Script Functions

General Calculation Functions

Name

CalculateAtomicScatteringFactors Calculates the atomic	
	scattering factors for a
	given atomic element and
	places them in a file
CalculatExitWave	Calculates the exit wave for
	the simulation currently open
CalculateImage	Calculates the image for the
	simulation currently open
CalculatePotential	Calculates the potential for
	the simulation currently open
CalculateImageFromWave	Calculates an image from a
	complex exit wave, given a
	microscope
CalculateLinearImageFromWave	Calculates a linear image
	from a complex exit wave,
	given a microscope
ApplyFocusPlate	Applies a focus plate (focus
	given in an image) to a

Summary

complex wavefunction
ShiftImageFocus
Shifts the focus of a given
complex wavefunction

PropagateWave

Calculates a 3D Complex

Volume Image containing the electron wavefunction at each

slice in the multislice calculation up to a given

thickness

Microscope Data Type

Declaration

Microscope mic

Initializing

Name	Summary
------	---------

Microscope mic Defines a default microscope Equates a microscope to

another microscope

Example:

Microscope mic mic.setvoltage(300)

Example:

Name

GetFocus

GetFocusSpread

Simulation ss

ss = GetSimulation() Get the Current Simulation

See data type below

ss = GetSimulation(String) Get the named Simulation

Microscope mic

Sets a default Microscope mic = ss.GetMicroscope() Assigns to simulation

Microscope

Summary

objective lens

objective lens

Returns the focus in Å of the

Returns the spread in focus

Microscope Class Member Functions

	<u> </u>
GetAperture	Returns the Aperture of the
	objective lens in 1/Å
GetApertureH	Returns the horizontal Center
	of Objective Lens Aperture in
	units of h of reciprocal
	space
GetApertureHK	Returns the Center of
	Objective Lens Aperture in
	units of h and k of
	reciprocal space
GetApertureK	Returns the Vertical Center
	of Objective Lens Aperture in
	units of k of reciprocal
	space
GetCs	Returns the Cs in mm of the
	objective lens
GetCs5	Returns the Cs5 in mm of the
	objective lens
GetDelta	Returns the Cs in mm of the
	objective lens
GetDivergence	Returns the Cs in mm of the

in Å of the objective lens

GetVoltage Returns the Cs in mm of the

objective lens

Print() Prints out a summary of the

microscope parameters Sets the Aperture of the objective lens in 1/Å

SetApertureH Sets the horizontal Center of

Objective Lens Aperture in units of h of reciprocal

space

SetApertureHK Sets the Center of Objective

Lens Aperture in units of h and k of reciprocal space Sets the Vertical Center of Objective Lens Aperture in units of k of reciprocal

space

SetCs Sets the Cs in mm of the

objective lens

SetCs5 Sets the Cs5 in mm of the

objective lens

SetDelta Sets the Cs in mm of the

objective lens

SetDivergence Sets the Cs in mm of the

objective lens

SetFocus Sets the focus in Å of the

objective lens

SetFocusSpread Sets the spread in focus in Å

of the objective lens

SetVoltage Sets the Cs in mm of the

objective lens

Simulation Data Type

Declaration

Simulation ss

SetAperture

SetApertureK

Initializing

Name	Summary
GetSimulation OpenSimulation	Gets the current simulation Sets the current simulation from an existing structure
	file

Simulation Class Member Functions

Name Summary

Galawlat and	(Pa) Galandatas tha
CalculateAll	(Re)Calculates the
	Potential(s), Exit Wave(s)
- 1 1	and Image(s).
Calculate3DPotential	Calculates the 3D potential
	for the unit cell of the
	current simulation
CalculateExitWave	Calculates the Exit Wave
CalculateImage	Calculates the Image
CalculatePotential	Calculates the Potential
CreateFrequencyImage	Returns a square image of a
	simulated object in
	reciprocal space.
CreateImage	Returns a square image from a
	given calculated image of
	given size and sampling
DisplayExitWave	Displays a given calculated
	exit wave for the simulation
DisplayExitWaveModulus	Displays the modulus of the
	exit wave
DisplayExitWavePhase	Displays the phase of the
	exit wave for the simulation
DisplayImage	Displays a given image for
	the simulation
DisplayPotential	Displays the calculated
	potential for the simulation
Focus	Sets the focus of the
	simulation
GetAperture	Returns the outer objective
	lens aperture (1/Å)
GetApertureAngle	Returns the outer objective
	lens aperture in mradians
GetApertureCenter	Returns the center of the
	objective lens aperture
GetApertureCenterHK	Returns the center of the
	objective lens aperture in
	(H,K) of the reciprocal space
	- · · · · ·

	- C - L h
Q ₀ +Q ₀	of the unit cell
GetCs	Returns the Spherical
0.+0.5	Aberration Cs in mm
GetCs5	Returns the 5 th order
	Spherical Aberration Cs5 in mm
GetDeltaFocus	Returns the increment in
	focus for the calculation
GetDeltaThickness	Returns the increment in
	thickness for the calculation
GetDivergence	Returns the convergence angle
_	(mrad) for the calculation
GetEndFocus	Returns the ending value for
	focus
GetEndThickness	Returns the ending value for
	thickness
GetExitWave	Returns an image containing a
	given number of unit cells of
	the exit wave of the
	calculation
GetExitWaveModulus	Returns an image containing a
	given number of unit cells of
	the modulus of the exit wave
GetExitWavePhase	Returns an image containing a
	given number of unit cells of
	the phase of the exit wave
GetFocus	Returns the focus (Å) for the
	calculation
GetFocusSpread	Returns the focus Spread (Å)
	for the calculation
GetImage	Returns an image containing
	the a given number of unit
	cells of calculated simulated
	image
GetInnerAperture	Returns the inner objective
	lens aperture (1/Å)
GetOpticAxis	Returns the center of the
	optic axis in tilt angle
	(mrad) and azimuthal angle
	(degrees)
GetOpticAxisHK	Returns the center of the
	optic axis in (H,K) of the
	reciprocal space of the unit
Cat Out and a sale	cell
GetOuterAperture	Returns the outer objective
CotDhagaChift	lens aperture (1/Å)
GetPhaseShift	Returns the phase shift for
CotDhagaChiftBading	the phase plate in units of π
GetPhaseShiftRadius	Returns the radius for the
GetPhaseShiftRadius2	phase plate in units of 1/Å Returns the outer radius for
GECFIIASESIIII CRAUIUSZ	
	the phase plate in units of 1/Å. Beams are blocked
	I/A. Dealls are Drocked

	between PhaseShiftRadius and PhaseShiftRadius2 if they are
GetPotential	different Returns an image containing a given number of unit cells of
GetStartFocus	Returns the starting focus
GetStartThickness	(Å) for a thru-focus series Returns the starting thickness (Å) for a thru-
GetThickness	thickness series Returns the thickness (Å) for the simulation
GetTilt	Returns the tilt angle of the specimen in mrad and the azimuthal angle of specimen tilt with respect to the
GetTiltAngle	horizontal axis in degrees Returns the tilt angle of the specimen in mrad
GetTiltDirection	Returns the azimuthal angle of specimen tilt with respect to the horizontal axis in
GetTiltH	degrees Gets the h value of the center of laue circle
GetTiltHK	<pre>(specimen tilt) Gets the h,k values of the center of laue circle</pre>
GetTiltK	(specimen tilt) Gets the k value of the center of laue circle
GetVibration	<pre>(specimen tilt) Gets the vibration of the "specimen" along x and y</pre>
GetVibrationX	Gets the vibration of the "specimen" along x
GetVibrationY	Gets the vibration of the "specimen" along y
GetVoltage	Returns the voltage of the microscope for the simulation
LoadExitWave	(kV) Loads a 1 by 1 unit cell of the Exit Wave as calculated and returns it as an image
LoadExitWaveModulus	Loads a 1 by 1 unit cell of the Exit Wave modulus as calculated and returns it as
LoadExitWavePhase	an image Loads a 1 by 1 unit cell of the Exit Wave Phase as calculated and returns it as
LoadImago	an image

LoadImage

Loads a 1 by 1 unit cell of

	the Image as calculated and returns it as an image
LoadPotential	Loads a 1 by 1 unit cell of the Potential as calculated
PropagateWave	and returns it as an image Calculates a 3D Complex Volume Image containing the electron wavefunction at each slice in the multislice calculation up to a given thickness
SetAperture	Sets the outer objective lens aperture $(1/\text{Å})$
SetApertureAngle	Sets the outer objective lens aperture in mradians
SetApertureCenter	Sets the center of the objective lens aperture
SetApertureHK	Sets the center of the objective lens aperture in (H,K) of the reciprocal space of the unit cell
SetCs	Sets the Spherical Aberration Cs in mm
SetCs5	Sets the 5 th order Spherical Aberration Cs5 in mm
SetDeltaFocus	Sets the Incremental focus (Å) for a thru-focus series
SetDeltaThickness	Sets the incremental thickness (Å) for a thru-thickness series
SetDivergence	Sets the convergence angle (mrad) for the calculation
SetEndFocus	Sets the ending value for focus [Å] in a thru-focus series
SetEndThickness	Sets the ending value for thickness [Å] in a thru-thickness series
SetFocus	Sets the focus (Å) for the calculation
SetFocusSpread	Sets the focus Spread (Å) for the calculation
SetInnerAperture	Sets the inner objective lens aperture $(1/\text{Å})$
SetOpticAxis	Sets the center of the optic axis in tilt angle (mrad) and azimuthal angle (degrees)
SetOpticAxisHK	Sets the center of the optic axis in (H,K) of the reciprocal space of the unit cell
SetOuterAperture	Sets the outer objective lens aperture (1/Å)

SetPhaseShift Sets the phase shift for the

phase plate in units of π

GetPhaseShiftRadius Sets the radius for the phase

plate in units of 1/Å

Sets the outer radius for the GetPhaseShiftRadius2

phase plate in units of 1/Å. Beams are blocked between

PhaseShiftRadius and

PhaseShiftRadius2 if they are

different

SetStartFocus Sets the starting focus (Å)

for a thru-focus series Sets the starting thickness for a thru-thickness series

SetThickness Sets the thickness (Å) for

the calculation

Sets the tilt angle of the SetTiltAngle

specimen in mrad

Sets the azimuthal angle of SetTiltDirection

specimen tilt with respect to

the horizontal axis in

degrees

Sets the h value of the SetTiltH

center of laue circle

(specimen tilt)

SetTiltHK Sets the h,k values of the

center of laue circle

(specimen tilt)

SetTiltK Sets the k value of the

center of laue circle

(specimen tilt)

SetVibration Sets the vibration of the

> "specimen" along x and y Sets the vibration of the

SetVibrationX "specimen" along x

Gets the vibration of the

"specimen" along y

SetVoltage Sets the voltage of the

microscope for the simulation

(kV)

Thickness Returns the thickness for the

calculation

Example:

Simulation ss = getsimulation() Number cs = 0.5 // Cs in mm

SetStartThickness

Number voltage = 300// voltage in kV

ss.setcs(cs)

ss.setvoltage(voltage)

SetVibrationY

// Assume that the potential has already been calculated

```
// as our changes only require the exit wave(s) (change in wavelength)
         // and the image(s) to be recalculated
         ss.showpotential(1,5,5)
         ss.calculateexitwave()
         ss.calculateimage()
         // Display the exit wave. The first of whatever number calculated
         // 5 by 5 unit cell
         image xw = ss.getexitwave(1,5,5) //
         xw.phase()
         xw.setname("Phase of exit wave")
         xw.show()
         // Show the image. The first of whatever number calculated
         // 5 by 5 unit cell
         image img = ss.getimage(1,5,5)
         img.setname("Calculated Image")
         img.show()
Example:
         Simulation ss = getsimulation()
                                                             // Get current simulation
         image3d test
                                                             // Declare a 3D volume image
         ss.calculate3dpotential(test)
                                                             // Calculate the 3D potential
         test.display()
                                                             // into test and display
                                                             // Image sections are traversed
                                                             // using the arrow keys
Example:
         Simulation ss = getsimulation()
                                                            // Get current simulation
         image tt = ss.loadimage()
                                                            // Load the image
         tt.fft()
                                                            // Fourier transform
         image dp = ss.createfrequencyimage(tt)
                                                            // Create image of fourier transform
                                                            // with default size 512
                                                            // Show the frequency image
         dp.show()
                                                            // Do the same for the diffraction
         tt = ss.loadexitwave()
                                                            // pattern
         tt.fft()
         image dp2 = ss.createfrequencyimage(tt)
         dp2.show()
```

Alphabetical description of general script functions and class member functions

abs

SUMMARY Calculates the absolute value of a real/complex

 $\hbox{number or the absolute values of a real/complex}\\$

image

SYNTAX number abs(number)

SYNTAX number abs(complexnumber)

SYNTAX image abs(image)

SYNTAX image abs(compleximage)

SYNTAX void image.abs() Image member function

DESCRIPTION Calculates the absolute value of a complex number or

image. (also known as the modulus of a complex
number) Calculates the absolute value(s) of a real

number of real image

ac

SUMMARY Calculates the autocorrelation function of a real

image

SYNTAX image ac(image)

SYNTAX void image.ac() Image member function

acos

SUMMARY Calculates the arccosine of a real number or a real

image

SYNTAX number acos(number)

SYNTAX image acos(image)

SYNTAX void image.acos() Image member function

acosh

SUMMARY Calculates the hyperbolic arccosine of a real number

or a real image

SYNTAX number acosh(number)

SYNTAX image acosh(image)

SYNTAX void image.acosh() Image member function

Addlmage

SUMMARY Adds an image to an image stack

void imagestack.addimage(image) SYNTAX Image stack

member function

AddImageToMovie

SUMMARY Adds an image to an existing open movie

SYNTAX void AddImageToMovie (image)

DESCRIPTION Adds an image to an existing open movie.

AddPeakList

Add a peaklist to an image merging with an existing SUMMARY

peaklist (if any).

void AddPeakList(image theImage, image peaklist) SYNTAX

DESCRIPTION After reading in a peaklist from a file or getting

> the peaklist from an image, this peaklist can be added to an existing image. The peaklist merges with any existing peaklist associated with the image. The dimensions of the image to be associated the

peaklist must be of the same dimensions as the image from which the peaklist originated for this to make

sense.

AddWindowToMovie

SUMMARY Adds an image to an existing open movie SYNTAX void AddWindowToMovie (image)

DESCRIPTION Adds a window (referenced by a displayed image) to

an existing open movie.

AdjustAngle

SUMMARY Adjusts the angle of the image if different from 90

SYNTAX void image.AdjustAngle() Image member function

DESCRIPTION Adjusts the image so that it has an angle of 90

degrees. This is applicable for images returned from a simulation. In this case the image represents a periodic object and the angle of the unit cell may

be different from 90 deg.

AdjustSampling

SUMMARY Adds an image to an image stack

SYNTAX void image.AdjustSampling(image) Image member

function

DESCRIPTION Adjusts the image so that it has equal sampling in x

and y. This is applicable for images returned from a simulation. In this case the image represents a periodic object and the sampling along the a and b

axes may be different.

AiryAi

SUMMARY Calculates the Airy Ai function

SYNTAX number AiryAi(number)

DESCRIPTION *Not Implemented

AiryBi

SUMMARY Calculates the Airy Bi function

SYNTAX number AiryBi(number)

DESCRIPTION

Align

SUMMARY Aligns two images

SYNTAX complexnumber aliqn(image x, image y [, number

method] [, number freqCutoff [, number focusShift]

[,number voltage])

DESCRIPTION Aligns image y with image x using either

crosscorrelation or phasecorrelation. Only argument 1 and 2 are required. The others are optional. Default values are method = 0 (crosscorrelation = 0, phasecorrelation =1), freqCutoff = 0.3*maxFrequency, focusShift = 0[Å], voltage = 300 [kV] Returns the shift used to translate image y in a complex number

AlignImages

SUMMARY Aligns two images

SYNTAX AlignImages (image x, image y [, number method] [,

number freqCutoff [, number focusShift] [,number

voltage])

DESCRIPTION Equivalent to Align. Aligns image y with image x

using either crosscorrelation or phasecorrelation. Only argument 1 and 2 are required. The others are

optional. Default values are method = 0

(crosscorrelation = 0, phasecorrelation =1),
freqCutoff = 0.3*maxFrequency, focusShift = 0[Å],

voltage = 300 [kV]

AlignTwoImages

SUMMARY Aligns two images

SYNTAX complexnumber AlignTwoImages(image x, image y [, number method] [, number freqCutoff [, number

focusShift] [,number voltage])

DESCRIPTION Equivalent to Align. Aligns image y with image x

using either crosscorrelation or phase correlation. Only argument 1 and 2 are required. The others are

optional. Default values are method = 0
(crosscorrelation = 0, phasecorrelation =1),

freqCutoff = 0.3*maxFrequency, focusShift = 0[Å],

voltage = 300 [kV] Returns the shift used to
translate image y in a complex number

Amplitude

SUMMARY Returns the modulus of a complex number/image/

image3D as a real number/image

SYNTAX number amplitude(complexnumber)

SYNTAX image amplitude(compleximage)

SYNTAX void image.amplitude() // Class Member Function

SYNTAX void image3D.amplitude()// Class Member Function

AnalyzeDiffractogram*

SUMMARY Analyzes a diffractogram

SYNTAX void AnalyzeDiffractogram(image , numbervariable

defocus, numbervariable direction, numbervariable

err)

DESCRIPTION *Not Implemented -- Analyze diffractogram in image.

Returned defocus, astigmatism, and err are in nm

Angle

SUMMARY Returns the phase of a complex number in degrees

SYNTAX number complexnumber.angle()

AnnotationType

SUMMARY Returns the type of an annotation

SYNTAX number AnnotationType (image , number

annotationID)

DESCRIPTION Returns the type of the annotation specified in the

given image with the given index.

AnnularHighpassFilter

SUMMARY Applies a high pass filter to an image

SYNTAX image AnnularHighPassFilter(image , number cutoff

[, number edgewidth])

SYNTAX void image.AnnularHighPassFilter(number cutoff [,

number edgewidth]) // Image member function

If the image is calibrated in \mathring{A} , the cutoff is in 1/ \mathring{a}

Å

DESCRIPTION edgewidth by default is set to 0 and represents a

soft edge

AnnularLowpassFilter

SUMMARY Applies a low pass filter to an image

SYNTAX image AnnularLowPassFilter(image , number cutoff [,

number edgewidth])

SYNTAX void image.AnnularLowPassFilter(number cutoff [,

number edgewidth]) // Image member function

If the image is calibrated in \mathring{A} , the cutoff is in 1/

Å

DESCRIPTION edgewidth by default is set to 0 and represents a soft edge

ApplyAnnularMask

SUMMARY Applies an annular mask to an image

SYNTAX image ApplyAnnularMask(image , number r1, number r2

[, number edgewidth] [, number isopaque])

SYNTAX void image.ApplyAnnularMask(number r1, number r2 [, number edgewidth] [, number isopaque]) // Image

member function

If the image is calibrated in Å, the values r1 and

r2 are in 1/Å

DESCRIPTION

Annular mask of inner radius r1 and outer radius r2. By default the width of the edge = 0 and by default isopaque = false

ApplyCircularMask

SUMMARY Returns an image resulting from the application of an annular mask to an image

SYNTAX void ApplyCircularMask (image , number r, [, number edgewidth] [, number isopaque]) // In place

operation

If the image is calibrated in $\mbox{\normalfont\AA},$ the values r is in $1/\mbox{\normalfont\AA}$

SYNTAX void image.ApplyCircularMask ([number edgewidth] [, number isopaque]) // In place operation

DESCRIPTION Circular mask of radius r. By default the width of

the edge = 0 and by default isopaque = false

ApplyCosineMask

SUMMARY Returns an image resulting from the application of a

circular cosine mask to an image

SYNTAX void ApplyCosineMask(image) // In place operation

SYNTAX void image.ApplyCosineMask() // Member function

ApplyFocusPlate

SUMMARY Returns an image resulting from the application of a

arbitrary focus plate to a complex image or wave

function

SYNTAX ComplexImage ApplyFocusPlate(compleximage source,

image focus [, number voltage = 300] [, number

sampling = 0.2])

SYNTAX void ApplyFocusPlate(image focus [, number voltage =

300] [, number sampling = 0.2]) // Image member

function

DESCRIPTION The focus variation (or constant) is given in the

image focus. The complex image is propagated over

the distance focus (which can vary as a function of

position). By default the voltage is 300kV. If the source is calibrated in Angstrom or nanometer, the sampling is taken from the source. Otherwise the default is 0.2 Å/pixel and must be set if different.

ApplyHanningMask

SUMMARY Returns an image resulting from the application of a circular hanning mask to an image

SYNTAX void ApplyHanningMask(image) // In place operation

SYNTAX void image.ApplyHanningMask() // Member function

asin

SUMMARY Calculates the arcsine of a real number or a real

image

number asin(number) SYNTAX

image asin(image) SYNTAX

void image.asin() SYNTAX Image member function

asinh

SUMMARY Calculates the hyperbolic arcsine of a real number

or a real image

SYNTAX number asinh(number)

SYNTAX image asinh(image)

SYNTAX void image.asinh() Image member function

atan2

SUMMARY Calculates the arctangent of y/x for real numbers,

real images of a complex image

SYNTAX number atan2(number x, number y) // atan(y/x) SYNTAX image atan2(image x, image y)

SYNTAX void image.atan2() Image member function

atanh

SUMMARY Calculates the hyperbolic arctangent of a real

number or a real image

SYNTAX number atanh(number)

SYNTAX image atanh(image)

SYNTAX void image.atanh() Image member function

Autocorrelate

SUMMARY Calculates the autocorrelation function of a real

image

SYNTAX image autocorrelate(image)

SYNTAX void image.autocorrelation() Image member function

BeginFill**

SUMMARY Starts a fill from projections

SYNTAX void image.beginfill() // image class member

function

SYNTAX void image3D.beginfill() // image3d class member

function

DESCRIPTION BeginFill and EndFill must bracket the filling from

projections.

Bessel $I_{\alpha}(x)$

SUMMARY Calculates the general Bessel I function (first

kind) of order alpha

SYNTAX number BesselI(number alpha, number x)

DESCRIPTION

Bessel J_n(x)

SUMMARY Calculates the general Bessel J function (first

kind) of order alpha

SYNTAX number BesselJ(number n, number x) or

image BesselJ(number n, number sizeOfImage, number

minX, number maxX)

BesselJN(number n, number x) or

image BesselJN(number n, number sizeOfImage, number

minX, number maxX)

DESCRIPTION

Bessel J₀(x)

SUMMARY Calculates the Bessel J function (first kind) of

order 0

SYNTAX number BesselJ0(number x)

DESCRIPTION

Bessel J₁(x)

SUMMARY Calculates the general Bessel J function (first

kind) of order 1

SYNTAX number BesselJ1(number x)

DESCRIPTION

Bessel $K_{\alpha}(x)$

SUMMARY Calculates the general Bessel K function (second

kind) of order alpha

SYNTAX number BesselK(number alpha, number x)

DESCRIPTION

Bessel $Y_n(x)$

SUMMARY Calculates the general Bessel Y function (second

kind) of order n

SYNTAX number BesselY(number n, number x) or

image BesselY(number n, number x, number sizeOfImage, number minX, number maxX)

number BesselYN(number n, number x) or

image BesselYN(number n, number x, number sizeOfImage, number minX, number maxX)

DESCRIPTION

Bessel $Y_{\alpha}(x)$

SUMMARY Calculates the general Bessel Y function (second

kind) of order alpha

SYNTAX number BesselY(number alpha, number x)

DESCRIPTION

Bessel $Y_{\alpha}(x)$

SUMMARY Calculates the general Bessel Y function (second

kind) of order alpha

SYNTAX number BesselY(number alpha, number x)

DESCRIPTION

Beta*

SUMMARY Calculates the beta function

SYNTAX number Beta (number, number)

DESCRIPTION *Not Implemented

bgs

SUMMARY Applies a Background Noise Subtraction Filter on a

real image

SYNTAX void image.bgs()

DESCRIPTION Attempts to subtract out an amorphous background

from an image containing crystalline material. In general the WienerFilter is a safer filter from a

statistical point.

BinomialCoefficient

SUMMARY Calculates the binomial coefficient

SYNTAX number BinomialCoefficient (number, number)

DESCRIPTION Returns the binomial coefficient ${}_{n}C_{k}$

BinomialRandom*

SUMMARY Calculates a random number with binomial

distribution

SYNTAX number BinomialRandom (number, number)

DESCRIPTION *Not Implemented

CC

SUMMARY Returns an image resulting from the cross-

correlation of two images

SYNTAX image cc(image x, image y)

ccd

SUMMARY Corrects for CCD detector bad pixels in a real image

SYNTAX image ccd(image)

SYNTAX void image.ccd()

DESCRIPTION

Attempts to locate pixels that correspond to bad pixels in the CCD camera. The pixel values fall out of the normal range and are substituted by mean values of the neighborhood

ceiling

SUMMARY Limits all values of a real image to a given maximum

value

SYNTAX image ceiling(image , number)

SYNTAX void image.ceiling(number) Image member function

cis

SUMMARY Calculates a unit vector in the complex plane

SYNTAX compleximage cis(image x, image y)

DESCRIPTION Returns the complex image (cos(x), sin(x))

clip

SUMMARY Limits all values of a real image to given minimum

and maximum values

SYNTAX image clip(image , number min, number max)

SYNTAX void image.clip(number min, number max) Image

member function

CloseMovie

SUMMARY Closes an open movie

SYNTAX void CloseMovie ()

complex

SUMMARY Creates a complex number/image from two real

numbers/images

SYNTAX complexnumber complex(number x, number y) // x +iy

SYNTAX compleximage complex(image x, image y) // x + iy

complexconjugate

SUMMARY Returns the complex conjugate of a complex number/

image

SYNTAX complexnumber complexconjugate (complexnumber)

SYNTAX compleximage complexconjugate (compleximage)

ComplexModulusSq / cmsq

SUMMARY Returns the complex modulus square of a complex

image.

SYNTAX compleximage ComplexModulusSq(compleximage)

SYNTAX void image.ComplexModulusSq() // Member Function

SYNTAX void image.cmsq() // Member Function

DESCRIPTION This replaces a complex image with the product of

itself and its complex conjugate. It is the complex

modulus square. Imaginary part is zero

conjugate

SUMMARY Returns the complex conjugate of a complex number/

image

SYNTAX complexnumber conjugate(complexnumber)

SYNTAX compleximage conjugate(compleximage)

SYNTAX void image.conjugate(number) Image member function

SYNTAX number complexnumber.conjugate() complex number

member function

ContinueCancelDialog

SUMMARY Continue cancel dialog

SYNTAX Boolean ContinueCancelDialog(String prompt)

DESCRIPTION Puts up a dialog with both a Continue button and

Cancel button. Returns true for Continue and false

for Cancel.

Convolve

SUMMARY Returns the convolution of two images

SYNTAX image convolve(image x, image y)

DESCRIPTION Equivalent to Convolute

Convolute

SUMMARY Returns the convolution function of two images

SYNTAX image convolve(image x, image y)

DESCRIPTION Equivalent to Convolve

Correlate

SUMMARY Returns the correlation function of two images

SYNTAX image correlate(image x, image y)

DESCRIPTION

COS

SUMMARY Calculates the cosine of a real number or a real

image

SYNTAX number cos(number)

SYNTAX image cos(image)

cosh

SUMMARY Calculates the hyperbolic cosine of a real number or

a real image

SYNTAX number cosh(number)

SYNTAX image cosh(image)

SYNTAX void image.cosh() Image member function

CountAnnotations

SUMMARY Returns the number of annotations in an image

SYNTAX Number CountAnnotations (Image)

DESCRIPTION Returns the number of annotations contained in the

image as a number.

CreateArrowAnnotation

SUMMARY Creates an arrow annotation

SYNTAX Number CreateArrowAnnotation(Image, Number top,

Number left, Number bottom, Number right)

DESCRIPTION Creates an arrow annotation in the given image with

the given endpoints. Returns the ID to the new

annotation as a number.

CreateDoubleArrowAnnotation

SUMMARY Creates a double arrow annotation

SYNTAX Number CreateDoubleArrowAnnotation(Image, Number

top, Number left, Number bottom, Number right)

DESCRIPTION Creates a double arrow annotation in the given image

with the given endpoints. Returns the ID to the new

annotation as a number.

CreateComplexImage

SUMMARY Creates a complex image of a given size

SYNTAX image CreateComplexImage(string name, number width,

number height)

DESCRIPTION Returns a Complex image with the given name and

dimensions

CreateFloatImage

SUMMARY Creates a real image of a given size

SYNTAX image CreateFloatImage(string name, number width,

number height)

SYNTAX image CreateFloatImage(number width, number height)

DESCRIPTION Returns a real image with the given name and

dimensions. Equivalent to "CreateImage", "RealImage"

and "NewImage"

CreateImage

SUMMARY Creates a real image of a given size

SYNTAX image CreateImage(string name, number width, number

height)

SYNTAX image CreateImage(number width, number height)

DESCRIPTION Returns a real image with the given name and

dimensions. Equivalent to "CreateFloatImage",

"RealImage" and "NewImage"

CreateLineAnnotation

SUMMARY Creates a line annotation

SYNTAX Number CreateLineAnnotation(Image, Number top,

Number left, Number bottom, Number right)

DESCRIPTION

Creates a line annotation in the given image with the given endpoints. Returns the ID to the new annotation as a number.

CreateNewMovie

SUMMARY Creates and opens a movie

SYNTAX void CreateNewMovie (string movieName)

CreateOvalAnnotation

SUMMARY Creates an oval annotation

SYNTAX Number CreateOvalAnnotation(Image, Number top,

Number left, Number bottom, Number right)

DESCRIPTION Creates an oval annotation in the given image with

the given coordinates. Returns the ID to the new

annotation as a number.

CreateTableFromImage

SUMMARY Displays the image as a table of numbers

SYNTAX void CreateTableFromImage (image)

DESCRIPTION Will create a table representing the content of an

image. Equivalent to "DisplayAsTable"

CreateTextAnnotation

SUMMARY Creates a text annotation

SYNTAX Number CreateTextAnnotation(Image, Number top,

Number left, String text)

DESCRIPTION Creates a text annotation in the given image in the

box specified by the coordinates. Returns the ID to

the new annotation as a number.

CreateVectorMap

SUMMARY Creates a vector map from two images

SYNTAX void CreateVectorMap(image x, image y [, number

samplingX] [, number samplingY] [, number scale])

DESCRIPTION Creates and displays a vector map from two images x

and y which correspond to the x and y components of the vectors. Vectors will be created every sampling X

(default=16) pixels and samplingY (default=16)
pixels. Vectors are drawn with the magnification

factor: scale (default=10)

CrossCorrelate

SUMMARY Returns the correlation function of two images

SYNTAX image crosscorrelate(image x, image y)

DESCRIPTION Equivalent to cc, correlate and crossscorrelation

CrossCorrelation

SUMMARY Returns the correlation function of two images

SYNTAX image crosscorrelate(image x, image y)

DESCRIPTION Equivalent to cc, correlate and crossscorrelate

CrossProduct

SUMMARY Calculates the cross product

SYNTAX RealImage CrossProduct(RealImage a, RealImage b)

DESCRIPTION Calculates the cross product of two 3 element

images.

DateStamp

SUMMARY Returns date and time

SYNTAX String DateStamp(void)

DESCRIPTION

Returns a string representing the current date and time.

Delay

SUMMARY Delay execution of the script x number of 1/60th of a

second

SYNTAX void Delay (number)

DeleteAnnotation

SUMMARY Deletes an annotation

SYNTAX void DeleteAnnotation(Image, Number annotationID)

DESCRIPTION Deletes the annotation specified by the annotation

ID in the given image.

Deletelmage

SUMMARY Deletes an image. Deletes an image in an image stack

SYNTAX void DeleteImage(image)

SYNTAX void imagestack.deleteimage(image) Image

member function

DeselectAnnotation

SUMMARY Deselects an annotation

SYNTAX void DeselectAnnotation(Image, Number

annotationID)

DESCRIPTION Deselects the annotation specified by the annotation

ID in the given image.

Display

SUMMARY Displays an image

SYNTAX void Display(image)

SYNTAX void image.Display() // Class member

SYNTAX void image3D.Display() // Class member

SYNTAX void imagestack.Display() // Class member

DisplayAsTable

SUMMARY Displays the image as a table of numbers

SYNTAX void DisplayAsTable(image)

DESCRIPTION Will create a table representation of the image.

Currently the image does not change its representation as in DM, but rather creates a

separate table. Equivalent to "CreateTableFromImage"

DisplayAt

SUMMARY Displays the image in a window at the given position

SYNTAX void DisplayAt(image, number x, number y)

DESCRIPTION x and y are the top left coordinates of the window

DisplayOnLogScale

SUMMARY Determines if an image is to be displayed on a log

scale

SYNTAX void DisplayOnLogScale(image, number log)

SYNTAX void image.DisplayOnLogScale(number log) // Class

Member

DESCRIPTION Sets if the image is to be displayed on a logscale

"log" set to 1 (true) or 0 (false)

distance

SUMMARY Calculates the pythagorean theorem

SYNTAX number distance(number x, number y)

DESCRIPTION Returns sqrt(x*x + y*y).

Doevents

SUMMARY Checks for input from the keyboard. Useful to check

for interrupts in a loop or for control

SYNTAX void Doevents ()

DotProduct

SUMMARY Calculates the inner product (dot-product) between

to real images (vectors)

SYNTAX number dotproduct(image img1, image img2)

EndFill**

SUMMARY Ends a fill from projections

SYNTAX

DESCRIPTION

erf

SUMMARY Calculates the error function

SYNTAX number erf(number)

DESCRIPTION

erfc

SUMMARY Calculates the complement of the error function

SYNTAX number erfc(number)

ErrorDialog

SUMMARY Puts up a dialog with an error number

SYNTAX void ErrorDialog(number)

Exit

SUMMARY Exit from the script

SYNTAX void Exit ()

exp

SUMMARY Calculates the exponential of a real/complex number

or a real/complex image

SYNTAX number exp(number)

SYNTAX complexnumber exp(complexnumber)

SYNTAX image exp(image)

SYNTAX compleximage exp(compleximage)

SYNTAX void image.exp() Image member function

exp1

SUMMARY Calculates the exponential of a real number or a

real image and subtracts 1

SYNTAX number exp1(number)

SYNTAX image expl(image)

SYNTAX void image.exp1() Image member function

exp2

SUMMARY Calculates 2 raised to the power of a real number or

a real image

SYNTAX number exp2(number)

SYNTAX image exp2(image)

SYNTAX void image.exp2() Image member function

exp10

SUMMARY Calculates 10 raised to the power of a real number

or a real image

SYNTAX number expl0(number)

SYNTAX image expl0(image)

SYNTAX void image.exp10() Image member function

ExpandSelection

SUMMARY Expands the selection of an image

SYNTAX void ExpandSelection(Image)

DESCRIPTION Expands the selection in the given image to fit the

entire image.

ExponentialRandom

SUMMARY Calculates a random number with exponential

distribution

SYNTAX number ExponentialRandom()

DESCRIPTION

exprsize

SUMMARY Allocates an image of a given size and optionally

assigns it to an expression

SYNTAX image exprsize(number width, number height)

SYNTAX compleximage exprsize(number width, number height)

SYNTAX image exprsize(number width, number

height,realimageexpression)

SYNTAX compleximage exprsize(number width, number

height,realimageexpression)

exprsize3

SUMMARY Allocates a volume (3D) image of a given size and

optionally assigns it to an expression

SYNTAX image exprsize3(number width, number height, number

height)

SYNTAX compleximage exprsize3(number width, number

height , number height)

SYNTAX image exprsize(number width, number height, number

height ,realimageexpression)

SYNTAX compleximage exprsize(number width, number height,

number height ,realimageexpression)

extract

SUMMARY Returns an image from a region of another image

SYNTAX image extract(image, number centerX, number centerY

, number width, number height)

factorial

SUMMARY Calculates the factorial of a real number or a real

image

SYNTAX number factorial(number)

SYNTAX image factorial(image)

SYNTAX void image.factorial() Image member function

DESCRIPTION The values are rounded to the nearest integer. The

factorial of values less than 1 are returned as 0

FFT

SUMMARY Takes the forward Fourier transform of an image, a

volume image or an image within an imagestack or the

entire imagestack

SYNTAX image fft(image)

SYNTAX image3D fft(image3D)

SYNTAX void image.fft() Image member function

SYNTAX void image3D.fft() Image member function

SYNTAX void imagestack.fft(number) Image member function

SYNTAX void imagestack.fft() Image member function

DESCRIPTION

FillFromProjection**

SUMMARY Fills in a 2D image from 1D projections

SYNTAX

DESCRIPTION

FindMaxima

SUMMARY Finds the minima in an image

SYNTAX void FindMaxima(Image, [number minValueForPeak],

[number minPeakDistance], [number cmRadius], [number

distanceFromEdgde])

SYNTAX void image.FindMaxima([number minValueForPeak],

[number minPeakDistance], [number cmRadius], [number

distanceFromEdgde])

DESCRIPTION Look for maxima in the image. minValueForPeak is the

smallest value in the image to be considered to be a peak. CmRadius is the center of mass radius used for defining the peak. minPeakDistance is the smallest distance allowed between peaks. distanceFromEdgde is the closest proximity to the edge of the image that

is searched for peaks. Default values if not specified are: minValueForPeak = imageMax -

0.2*imageRange, minPeakDistance = 0, cmRadius = 0 , distanceFromEdgde = 0

FindMinima

SUMMARY Finds the minima in an image

SYNTAX void FindMinima (Image, [number maxValueForPeak], [number minPeakDistance], [number cmRadius], [number

distanceFromEdgde])

SYNTAX void image.FindMinima([number maxValueForPeak] , [number minPeakDistance], [number cmRadius], [number

distanceFromEdgde])

DESCRIPTION Look for minima in the image. maxValueForPeak is the largest value in the image to be considered to

be a peak. CmRadius is the center of mass radius used for defining the peak. minPeakDistance is the

smallest distance allowed between peaks.

distanceFromEdgde is the closest proximity to the edge of the image that is searched for peaks.

Default values if not specified are: maxValueForPeak = imageMin + 0.2*imageRange, minPeakDistance = 0,

cmRadius = 0 , distanceFromEdgde = 0

FindPattern

SUMMARY Returns the position dependent cross-correlation coefficient between an image and a pattern for each

position of the pattern within the image

SYNTAX image FindPattern(image sourceImage [. Image

template] [,number normalize])

This function performs a cross correlation between DESCRIPTION the sourceimage and the template for each possible position of the template within the image. If the

> sourceImage has a selection, the template needs not be specified as the selection is used as the template. The argument normalize is set to true/ false (default = false) to set if the source and template are normalized to zero mean before the cross correlation is taken. Equivalent to

"TemplateMatch"

FindPeaks

SUMMARY Finds peaks in an image

SYNTAX void FindPeaks(Image, [number minValueForPeak],

[number minPeakDistance], [number cmRadius], [number

distanceFromEdgde])

SYNTAX void image.FindPeaks([number minValueForPeak] ,

[number minPeakDistance], [number cmRadius], [number

distanceFromEdgde])

DESCRIPTION Look for maxima in the image. minValueForPeak is the

smallest value in the image to be considered to be a peak. CmRadius is the center of mass radius used for defining the peak. minPeakDistance is the smallest distance allowed between peaks. distanceFromEdgde is the closest proximity to the edge of the image that is searched for peaks. Default values if not

specified are: minValueForPeak = imageMax -

0.2*imageRange, minPeakDistance = 0, cmRadius = 0 ,

distanceFromEdgde = 0

FitDoublePeaks

SYNTAX

SUMMARY Fits a peak list to a set of double peaks (two peaks are close)

void FitDoublePeaks(image [number maxPeakSeparation]
[, number outputTable])

DESCRIPTION Fits the peaks found in an image to a set of Gaussian peaks. Peaks within a given distance

Gaussian peaks. Peaks within a given distance maxPeakSeparation (default = 10 pixels) are considered to be closely spaced Gaussian peaks. Optionally the parameters for the peaks can be output as a table (outputTable = false by default). The peaks in the image peaklist are updated to

reflect the Gaussian fit.

FitExponentials

SUMMARY Fits the peaks in a peak list to Exponential peaks

SYNTAX void FitExponentials(image [, number output = 0] [,number pixelsAcrossPeak = 26] [,number

minNumberofPixelsInPeak = 100])

DESCRIPTION

Fits the peaks found in an image to a set of Exponential peaks. Optionally the parameters for the peaks can be output as a table [1] or written to the log window[2]. pixelsAcrossPeak is an estimate of the numbers of pixels across the entire peak. minNumberofPixelsInPeak represents a minimum number of pixels that must be in a peak. The peaks in the image peaklist are updated to reflect the fit.

FitGaussians

SUMMARY

Fits the peaks in a peak list to Gaussian peaks

SYNTAX

void FitGaussians(image [, number output = 0] [,number pixelsAcrossPeak = 26] [,number minNumberofPixelsInPeak = 100])

DESCRIPTION

Fits the peaks found in an image to a set of Gaussian peaks. Optionally the parameters for the peaks can be output as a table [1] or written to the log window[2]. pixelsAcrossPeak is an estimate of the numbers of pixels across the entire peak. minNumberofPixelsInPeak represents a minimum number of pixels that must be in a peak. The peaks in the image peaklist are updated to reflect the fit.

FitLattice

SUMMARY

Fits an existing lattice to a peaklist

SYNTAX

void FitLattice(image [, number maxDeviation])

DESCRIPTION

The lattice defined on the image will be refined to minimize the sum squared distance from the lattice to the peaks in the peak list. Only peaks lying within the distance maxDeviation (fraction of a lattice vector) will be used in the fitting routine.

FitParabolas

SUMMARY

Fits the peaks in a peak list to Parabolic peaks

SYNTAX

void FitParabolas(image [, number output = 0] [,number pixelsAcrossPeak = 26] [,number minNumberofPixelsInPeak = 100])

DESCRIPTION

Fits the peaks found in an image to a set of Parabolic peaks. Optionally the parameters for the peaks can be output as a table [1] or written to the log window[2]. pixelsAcrossPeak is an estimate of the numbers of pixels across the entire peak. minNumberofPixelsInPeak represents a minimum number of pixels that must be in a peak. The peaks in the image peaklist are updated to reflect the fit.

FitPeaks

SUMMARY Fits the peaks in a peak list to Gaussian/

Exponential peaks

SYNTAX void FitPeaks(image [, number output = 0] [, number

peakShape = 0] [,number pixelsAcrossPeak = 26]

[,number minNumberofPixelsInPeak = 100])

DESCRIPTION Fits the peaks found in an image to a set of

Gaussian peaks. Optionally the parameters for the peaks can be output as a table [1] or written to the

log window[2]. peakShape (0=Gaussian),

(1=Exponential). pixelsAcrossPeak is an estimate of

the numbers of pixels across the entire peak.

image peaklist are updated to reflect the fit.

minNumberofPixelsInPeak represents a minimum number of pixels that must be in a peak. The peaks in the

FlipHorizontal

SUMMARY Flips an image horizontally (around the vertical

axis)

SYNTAX void FlipHorizontal(image)

SYNTAX void image.FlipHorizontal() // Class member

FlipVertical

SUMMARY Flips an image vertically (around the horizontal

axis)

SYNTAX void FlipVertical(image)

SYNTAX void image.FlipVertical() // Class member

floor

SUMMARY Limits all values of a real image to a given minimum

value

SYNTAX image floor(image , number)

SYNTAX void image.floor(number) Image member function

DESCRIPTION Sets all values < minVal to minVal

Gamma

SUMMARY Calculates the gamma of a real number

SYNTAX number Gamma(number)

DESCRIPTION

GammaP

SUMMARY Calculates the incomplete gamma function

SYNTAX number GammaP(number, number)

DESCRIPTION

GammaQ

SUMMARY Calculates the complement of the incomplete gamma

function

SYNTAX number GammaQ(number, number)

DESCRIPTION

GammaRandom*

SUMMARY Calculates a random number with gamma distribution

SYNTAX number GammaRandom()

DESCRIPTION *Not Implemented

GaussianLowPassFilter

SUMMARY Applies a Gaussian low pass filter

SYNTAX image GaussianLowPassFilter(image, number sigma)

DESCRIPTION Applies a Gaussian low pass filter of sigma in the

units of calibration unit of the image

GaussianHighPassFilter

SUMMARY Applies a Gaussian high pass filter

SYNTAX image GaussianHighPassFilter (image, number sigma)

DESCRIPTION Applies a Gaussian High pass filter of sigma in the

units of calibration unit of the image

GaussianRandom*

SUMMARY Calculates a random number with gaussian

distribution

SYNTAX number GaussianRandom()

DESCRIPTION

GetAnnotationRect

SUMMARY Gets the rectangle of the annotation

SYNTAX void GetAnnotationRect(Image, Number annotationID,

NumberVariable top, NumberVariable left,

NumberVariable bottom, NumberVariable right)

GetCalibration

SUMMARY Returns the calibration of the image

SYNTAX void GetCalibration(image, numbervariable scalex,

numbervariable scaley)

SYNTAX void GetCalibration(image, numbervariable scale)

SYNTAX number GetCalibration(image)

SYNTAX number image.GetCalibration() // Image Class Member

Function

DESCRIPTION In general the scale return for a single number is

the value stored in scaleX, which is normally the

same as scaleY

GetCalibrationUnit

SUMMARY Returns the calibration unit of the image

SYNTAX number GetCalibrationUnit(image)

SYNTAX String image.GetCalibrationUnit () // Image Class

Member Function

DESCRIPTION The non-class function returns a number. The index

numbers for the calibration units are: 0 - Pixels, 1 - Å, 2 - nanometer, 3 - 1/Pixels, 4 - 1/Å, 5 - 1/nm.

The class member function returns a string

representation of the unit

GetHeight

SUMMARY Returns the height in pixels of an image

SYNTAX number GetHeight(image)

Getlmage

SUMMARY Returns a 2D image from a given position (z) in a

volume image

SYNTAX image image3D.GetImage(number whichImage)

DESCRIPTION Returns an image which is a copy of the image at the

given depth in the volume image. The range for

whichImage is 0 - (Depth-1)

GetKey

SUMMARY Returns key

SYNTAX Number GetKey(void)

DESCRIPTION Returns the key that was last pressed as a number.

GetLattice

Returns the lattice (if defined) for the image SUMMARY

SYNTAX image GetLattice(image)

SYNTAX image image.GetLattice()

DESCRIPTION The lattice is returned in a 2 by 3 image. OriginX

is Lattice(0,0). OriginY is Lattice(1,0). UX is

Lattice(0,1). UY is Lattice(1,1). VX is

Lattice(0,2). VY is Lattice(1,2).

GetName

SUMMARY Return the name of the image

SYNTAX string GetName(image)

void GetName(image, stringvariable name) SYNTAX

string image.GetName() // Image Class member SYNTAX

function

GetNamedImage

SUMMARY Return the image with a given name

SYNTAX image GetNamedImage(string name)

SYNTAX void GetNamedImage(image , string name)

GetNumber

SUMMARY Prompt for a number using an OkCancelDialog. Returns

0 (False) if cancel is pressed. 1 (True) otherwise.

SYNTAX number GetNumber (string prompt, NumberVariable

val)

SYNTAX number GetNumber (string prompt, number default,

NumberVariable val)

GetNumberedImage

SUMMARY Return the image with a given name

SYNTAX image GetNumberedImage (number num)

SYNTAX void GetNumberedImage (image destImage, number num)

DESCRIPTION Returns the image with the label/tag A# as in A0,

A1, A2 etc...

GetNthAnnotationID

SUMMARY Get the ID of an annotation

SYNTAX Number GetNthAnnotationID(Image, Number index)

DESCRIPTION Returns the ID of the index'th annotation in the

image.

GetPeakList

SUMMARY Returns the peaklist (if defined) for the image

SYNTAX image GetPeakList(image)

SYNTAX image image.GetPeakList() // class member

DESCRIPTION Reaturns the peak list in the form of an image of

size 3 by numberPeaks. Column 0 - xposition, Column

1 - yposition, Column 2 - peakValue

GetPixel

SUMMARY Returns the pixel value for a given pixel

SYNTAX number GetPixel(image, number x, number y)

SYNTAX complexnumber GetPixel(compleximage, number x,

number y)

SYNTAX number image.GetPixel(number x, number y)

SYNTAX complexnumber compleximage.GetPixel(number x, number

y)

GetPixelAmplitude

SUMMARY Returns the pixel amplitude for a given pixel in a

complex image

SYNTAX number GetPixelAmplitude(compleximage, number x,

number y))

GetPixelPhase

SUMMARY Returns the pixel phase for a given pixel in a

complex image

SYNTAX number GetPixelPhase(compleximage, number x, number

у))

GetScale

SUMMARY Returns the scale/calibration of an image

SYNTAX void GetScale(image, numbervariable scalex,

numbervariable scaley)

SYNTAX void GetScale(image, numbervariable scale)

SYNTAX number GetScale(image)

SYNTAX number image.GetScale() // Image Class Member

Function

DESCRIPTION In general the scale return for a single number is

the value stored in scaleX, which is normally the

same as scaleY

GetSelection

SUMMARY Gets the selection rectangle of an image

SYNTAX Boolean GetSelection(Image, NumberVariable top,

NumberVariable left, NumberVariable bottom,

NumberVariable right)

DESCRIPTION Sets the given coordinate variables to the

coordinates of the current selection in the given

image. If the image has no selection, the coordinates are set to the size of the image.

Returns true if there was a selection, false if not.

GetSize

SUMMARY Returns the size of an image

SYNTAX void GetSize(image, numbervariable width,

numbervariable height)

SYNTAX void image.GetSize(numbervariable width,

numbervariable height) // Class member function

SYNTAX void image3D.GetSize(numbervariable width,

numbervariable height, numbervariable depth) //

Class member function

GetSurveyMode

SUMMARY Gets the method of survey technique for setting

black and white values

SYNTAX Number mode = GetSurveyMode(Image)

DESCRIPTION mode = 0 CrossHair . mode = 1 Entire Image,

Equivalent to GetSurveyTechnique

GetSurveyTechnique

SUMMARY Sets the method of survey technique for setting

black and white values

SYNTAX Number mode = GetSurveyTechnique (Image)

DESCRIPTION mode = 0 CrossHair . mode = 1 Entire Image,

Equivalent to GetSurveyMode

GetTwoImages

SUMMARY Two image dialog

SYNTAX Boolean GetTwoImages(String title, ImageVariable

image1, ImageVariable image2)

DESCRIPTION Puts up an Ok-Cancel dialog box and allows the user

to choose two images. Returns true for Ok and false

for Cancel.

GetTwoImagesWithPrompt

SUMMARY Two image dialog with prompt

SYNTAX Boolean GetTwoImagesWithPrompt(String prompt,

String title, ImageVariable image1, ImageVariable

image2)

DESCRIPTION Puts up an Ok-Cancel dialog box and allows the user

to choose two images. Returns true for Ok and false

for Cancel.

GetVoxel

SUMMARY Gets the voxel value at position (x,y,z)

SYNTAX number image3D.GetVoxel(number x,number y,number z)

SYNTAX complexnumber compleximage3D.GetVoxel(number

x,number y,number z)

GetWidth

SUMMARY Returns the width in pixels of an image

SYNTAX number GetWidth(image)

GetWindowPosition

SUMMARY Returns the window position of an image

SYNTAX

void GetWindowPosition(image numbervariable left,
numbervariable top)

GetWindowSize

SUMMARY Returns the window size for a displayed image

SYNTAX void GetWindowSize (image numbervariable width,

numbervariable height)

HasLattice

SUMMARY Returns true/false if a lattice is defined on an

image

SYNTAX number HasLattice(image)

SYNTAX number image.HasLattice() // class member

HasPeaklist

SUMMARY Returns true/false if a peak list is defined on an

image

SYNTAX number HasPeaklist(image)

SYNTAX number image.HasPeaklist() // class member

Height

SUMMARY Returns the height (in pixels) of an image

SYNTAX number image.height() // Image Member Function

SYNTAX number image3D.height() // Image3D Member Function

Highpass

SUMMARY Returns an image resulting from the application of a Annular High Pass filter to an image

SYNTAX image Highpass(image , number cutoff [, number

edgewidth])

DESCRIPTION Equivalent to AnnularHighPassFilter. edgewidth by

default is set to 0 and represents a soft edge

Highpassfilter

SUMMARY Returns an image resulting from the application of a

Annular High Pass filter to an image

SYNTAX image Highpassfilter(image , number cutoff [,

number edgewidth])

DESCRIPTION Equivalent to AnnularHighPassFilter. edgewidth by

default is set to 0 and represents a soft edge

HorizontalProjection

SUMMARY Returns an image resulting projecting the pixels

(summed) onto the horizontal (x) axis

SYNTAX image HorizontalProjection(image)

IFFT

SUMMARY Takes the inverse Fourier transform of a complex

image, a complex volume image or a complex image
within an imagestack or the entire imagestack

SYNTAX image ifft(compleximage)

SYNTAX image3D ifft(image3D)

SYNTAX void image.ifft() Image member function

SYNTAX void image3D.ifft() Image member function

SYNTAX void imagestack.ifft(number) Image member function

SYNTAX void imagestack.ifft() Image member function

imaginary / imag

SUMMARY Returns the imaginary portion of a complex number/

image as a real number/image

SYNTAX number imaginary(complexnumber)

SYNTAX image imaginary(compleximage)

SYNTAX void image.imaginary() Image member function

SYNTAX number complexnumber.imag() complex number member

function

intensity

SUMMARY Returns the modulus square of a complex number/image

as a real number/image

SYNTAX number intensity(complexnumber)

SYNTAX image intensity(compleximage)

SYNTAX void image.intensity() Image member function

Inverse

SUMMARY Inverts an image

SYNTAX void image.Inverse() // Member function

Invert

SUMMARY Inverts an image

SYNTAX image Inverse (image)

SYNTAX void image.Inverse() // Member function

IsAnnotationSelected

SUMMARY Checks if an annotation is selected

SYNTAX Boolean IsAnnotationSelected(Image, Number

annotationID)

DESCRIPTION Returns true if the annotation specified by the

annotation ID in the given image is selected;

returns true otherwise.

Laplacian

SUMMARY Takes the Laplacian of a real image

SYNTAX image Laplacian(image)

SYNTAX void image.Laplacian() // Member function

LegendrePolynomial

SUMMARY Calculates the Legendre polynomial function

SYNTAX number LegendrePolynomial(number, number, number)

DESCRIPTION

log

SUMMARY Calculates the natural logarithm of a real number or

a real image

SYNTAX number log(number)

SYNTAX image log(image)

SYNTAX void image.log() Image member function

log1

SUMMARY Calculates the logarithm of a real number or a real

image after first adding 1

SYNTAX number log1(number)

SYNTAX image log1(image)

SYNTAX void image.log1() Image member function

DESCRIPTION

First the argument is changed by adding 1 (useful when the image contains $0\,\mathrm{'s}$) and then the logarithm is taken

log2

SUMMARY Calculates the logarithm base 2 of a real number or

a real image

SYNTAX number log2(number)

SYNTAX image log2(image)

SYNTAX void image.log2() Image member function

log10

SUMMARY Calculates the logarithm base 10 of a real number or

a real image

SYNTAX number log10(number)

SYNTAX image log10(image)

SYNTAX void image.log10() Image member function

logGamma

SUMMARY Calculates the logGamma of a real number

SYNTAX number logGamma(number)

SYNTAX

Lowpass

SUMMARY Returns an image resulting from the application of

an Annular Low Pass filter to an image

SYNTAX image AnnularLowPassFilter(image , number cutoff [,

number edgewidth])

DESCRIPTION Equivalent to AnnularLowPassFilter. edgewidth by

default is set to 0 and represents a soft edge

Lowpassfilter

SUMMARY Returns an image resulting from the application of

an Annular Low Pass filter to an image

SYNTAX image Lowpassfilter(image , number cutoff [, number

edgewidth])

DESCRIPTION Equivalent to AnnularLowPassFilter. edgewidth by

default is set to 0 and represents a soft edge

MatrixDeterminant*

SUMMARY Returns the determinant of a matrix

SYNTAX number MatrixDeterminant (image)

DESCRIPTION *Not Implemented

MatrixInverse*

SUMMARY Inverts a real matrix

SYNTAX image MatrixInverse (image)

DESCRIPTION *Not Implemented

MatrixMultiply

SUMMARY Does a matrix multiplication of two real images

SYNTAX image MatrixMultiply (image, image)

MatrixPrint*

SUMMARY Prints out the values of a matrix / image

SYNTAX void MatrixPrint(image)

DESCRIPTION *Not Implemented

MatrixTranspose

SUMMARY Transposes the matrix representation of a real image

SYNTAX image MatrixTranspose (image)

max

SUMMARY Returns the maximum value of a real image. Can also

return the positions of the maximum. Calculate the min of two real number expressions or two images

SYNTAX number max(image)

SYNTAX number max(image, number xpos, number ypos)

SYNTAX number max(number, number)

SYNTAX void max(number, number , numbervariable result)

SYNTAX image max(image, image)

SYNTAX void max(image, imagevariable result)

SYNTAX number image.max() Image member function

SYNTAX number image.max(number xpos, number ypos) Image

member function

Maximum*

SUMMARY Calculates the maximum of a given list of real

numbers

SYNTAX number minimum (number, number, ...) up to a

maximum of 16 arguments

DESCRIPTION *Not yet implemented

mean

SUMMARY Returns the mean value of a real image.

SYNTAX number max(image)

SYNTAX number image.mean() Image member function

meansquare

SUMMARY Returns the mean square value of a real image.

SYNTAX number meansquare(image)

SYNTAX number image.meansquare() Image member function

median

SUMMARY Returns the median value of a real image or a list

of numbers.

SYNTAX number median(image)

SYNTAX number median(number x1, number x2, number x3...) up

to a maximum of 16 arguments

min

SUMMARY Returns the minimum value of a real image. Can also

return the positions of the minimum. Calculate the min of two real number expressions or two images

SYNTAX number min(image)

SYNTAX number min(image, number xpos, number ypos)

SYNTAX number min(number, number)

SYNTAX void min(number, number, numbervariable result)

SYNTAX image min(image, image)

SYNTAX void min(image, image, imagevariable result)

SYNTAX number image.min() Image member function

SYNTAX number image.min(number xpos, number ypos) Image

member function

Minimum*

SUMMARY Calculates the minimum of a given list of real numbers

SYNTAX number minimum (number, number, ...) up to a

maximum of 16 arguments

DESCRIPTION *Not yet implemented

modsq

SUMMARY Returns the modulus squareof a complex number

SYNTAX number complexnumber.modsq() // complex number

member function

modulus

SUMMARY Returns the modulus of a complex number/image/

image3D as a real number/image

SYNTAX number modulus(complexnumber)

SYNTAX image modulus(compleximage)

SYNTAX number complexnumber.modulus() // complex number

member function

SYNTAX void image.modulus() // Class Member Function

SYNTAX void image3D.modulus()// Class Member Function

MoveAnnotation

SUMMARY Moves an annotation

SYNTAX void MoveAnnotation(Image, Number annotationID,

Number top, Number left, Number bottom, Number right

)

DESCRIPTION Moves the annotation specified by annotation ID in

the given image to the specified coordinates.

Negate

SUMMARY Returns the inverse of an image

SYNTAX image Negate(image)

Newlmage

SUMMARY Creates a real image of a given size

SYNTAX image NewImage(string title, number width, number

height)

SYNTAX image NewImage(number width, number height)

norm

SUMMARY Calculates the norm of a real/complex number or a

real/complex image.

SYNTAX number norm(number)

SYNTAX number norm(complexnumber)

SYNTAX realimage norm(image)

SYNTAX realimage norm(compleximage)

SYNTAX void image.norm() Image member function

DESCRIPTION The norm of the real number is its square. The norm

of a complex number is its modulus square.

OffsetAnnotation

SUMMARY Offsets an annotation

SYNTAX void OffsetAnnotation(Image, Number annotationID,

Number deltax, Number deltay)

DESCRIPTION Offsets the annotation specified by annotation ID in

the given image by the specified offsets.

OkDialog

SUMMARY Ok dialog

SYNTAX void OkDialog(String prompt)

DESCRIPTION Puts up a dialog with an Ok button

OpenAndSetProgressWindow

SUMMARY Opens and sets the progress window

SYNTAX void OpenAndSetProgressWindow(String line1, String

line2, String line3)

OpenImage

SUMMARY Creates an image from an existing image file

SYNTAX image open(string filename)

SYNTAX void open(string filename, number width, number

height [number type = 7 (real)] [, number byteOffset

= 0] [, number swapBytes = 0])

DESCRIPTION Opens an existing image. If the image is fully

specified by its internal structure and is

supported, only the filename is needed as long as the path is set properly beforehand. If the image file contains raw image data, then image width,

height and optionally type, offset and swapbytes are needed.

OpenLogWindow

SUMMARY Opens the output window

SYNTAX void OpenLogWindow (void)

OpenResultsWindow

SUMMARY Opens the results window

SYNTAX void OpenResultsWindow(void)

DESCRIPTION Equivalent to OpenLogWindow. DM compatibility

function

OpenWithDialog

SUMMARY Creates an image from an existing image file chosen

through a file dialog

SYNTAX image OpenWithDialog()

OptionDown

SUMMARY Returns true/false depending on if the Option key is

down or not

SYNTAX Boolean OptionDown(void)

DESCRIPTION Returns 1 if the option key is down and 0 otherwise.

PadWithMean

SUMMARY Pads an image with its mean value to specified

dimensions

SYNTAX void image.PadWithMean(number newWidth, number

newHeight) // class member

PadWithZero

SUMMARY Pads an image with zero to specified dimensions

SYNTAX void image.PadWithZero(number newWidth, number

newHeight) // class member

Pi

SUMMARY Returns an approximation of π One can also just

write Pi which is a predefined constant

SYNTAX number pi()

phase

SUMMARY Returns	the	phase	of	а	complex	number/	'image/	/image3D
-----------------	-----	-------	----	---	---------	---------	---------	----------

as a real number/image

SYNTAX number phase(complexnumber)

SYNTAX image phase(compleximage)

SYNTAX number complexnumber.phase() // complex number

member function

SYNTAX void image.phase() // Image member

function

SYNTAX void image3D.phase() // Image3D member

function

PhaseCorrelate

SUMMARY Returns the phase correlation between two images

SYNTAX image PhaseCorrelate (image x, image y [, number

freqCutoff])

DESCRIPTION Calculate the phase correlation between two images

but using frequencies up to a maximum frequency cut

off "freqCutoff" default freqCutoff =

0.3*maxFrequency

PhaseCorrelation

SUMMARY Returns the phase correlation between two images

SYNTAX image PhaseCorrelation(image x, image y [, number

freqCutoff])

DESCRIPTION Calculate the phase correlation between two images

but using frequencies up to a maximum frequency cut

off "freqCutoff" default freqCutoff =

0.3*maxFrequency

PoissonRandom*

SUMMARY Calculates a random number with poisson distribution

SYNTAX number PoissonRandom()

Polar

SUMMARY Calculates the polar representation of a rectangular

complex number/image

SYNTAX complexnumber polar(complexnumber)

SYNTAX complexnumber polar(compleximage)

SYNTAX void image.polar() Image member function

DESCRIPTION Amplitude stored in real part. Phase stored in

imaginary part

Polynomial*

SUMMARY Calculates a polynomial expansion using a real image

 ${\tt expression}$

DESCRIPTION *Currently not implemented

pow

SUMMARY Calculates the exponential of a real/complex number

or a real/complex image

SYNTAX number pow(number x, number y) // x**y

SYNTAX image exp(image x, number y) // x**y

SYNTAX void image.pow(number x) Image member function

pow2

SUMMARY Calculates 2 raised to the power of a real number or

a real image

SYNTAX number pow2(number)

SYNTAX image pow2(image)

pow10

SUMMARY Calculates 10 raised to the power of a real number

or a real image

SYNTAX number pow10(number)

SYNTAX image pow10(image)

SYNTAX void image.pow10() Image member function

PowerSpectrum

SUMMARY Calculates the power spectrum of a real image

SYNTAX image PowerSpectrum(image)

SYNTAX void image.PowerSpectrum() // Image Member Function

product*

SUMMARY Calculates the product of a real/complex image

expression

SYNTAX Number product(RealImageExpression)

SYNTAX ComplexNumber product(ComplexImageExpression)

DESCRIPTION *Currently not implemented

PropagateWave

SUMMARY Calculates a 3D complex volume containing the wave

function at each slice for the current simulation $\ensuremath{\text{up}}$

to a given thickness.

SYNTAX Image3D PropagateWave(number thickness)

SYNTAX Image3D simulation.PropagateWave(number

thickness) // member function of the simulation

object

DESCRIPTION

Implemented as both a standalone function for an open simulation or as a member function of the class simulation.

ps

SUMMARY Calculates the power spectrum of a real image

SYNTAX image ps(image)

SYNTAX void image.ps() // Image Member Function

Radial Average

SUMMARY Returns the radial average of an image

SYNTAX image RadialAverage(image sourceImage [, number

mode])

DESCRIPTION Creates a new image of type mode that is a

representation of the radial average of sourceImage.
The optional argument mode represents: Mode = 1D ,

Mode = 1 2D Split Plane , Mode = 2 2D

ReadPeakList

SUMMARY Returns the peak list from a file

SYNTAX image ReadPeakList(string filename)

DESCRIPTION Returns the peak list in an image by reading a file

containg the list of peaks (saved by the program as a tab-delimited text file). The peaklist can then be

associated with an existing image through the

SetPeakList function.

real

SUMMARY Returns the real part of a complex number/image as a

real number/image

SYNTAX number real(complexnumber)

SYNTAX image real(compleximage)

SYNTAX number complexnumber.real() // complex number

member function

SYNTAX void image.real() // Image member

function

Reallmage

SUMMARY Creates a real image of a given size

SYNTAX image RealImage(string title, number numBytes,

number width, number height)

SYNTAX image RealImage(number width, number height)

DESCRIPTION Creates a real floating point image. Only 4 byte

real numbers are supported

RealFFT

SUMMARY Takes the forward Fourier transform of an image

SYNTAX image Realfft(image)

DESCRIPTION This does not compute a packed Fourier transform as

in DM, but is present so that there is an equivalent

syntax to DM scripting

Remainder

SUMMARY Calculates the integer remainder for real numbers or

real images

SYNTAX number remainder(number)

SYNTAX image remainder(image)

DESCRIPTION

Rect

SUMMARY Calculates the rectangular representation of a polar

complex number/image

SYNTAX complexnumber rect(complexnumber)

SYNTAX complexnumber rect(compleximage)

SYNTAX void image.rect() Image member function

RemoveCCDDefects

SUMMARY Corrects for CCD detector bad pixels in a real image

(ccd)

SYNTAX image RemoveCCDDefects(image)

SYNTAX void image.RemoveCCDDefects() //Member function

DESCRIPTION Equivalent to "ccd"

repeat

SUMMARY Repeats an image/image3D in the 2 or 3 dimensions

SYNTAX image repeat(image, number nx, number ny)

SYNTAX void image.repeat(number nx, number ny) Image

member function

SYNTAX void image3D.repeat(number nx, number ny, number nz)

Image3D member function

Resize

SUMMARY Resizes an image

SYNTAX image Resize(image , number width, number height)

SYNTAX void image.Resize(number width, number height)

DESCRIPTION Resizes the image using interpolation

RMS

SUMMARY Calculates the root mean square value of a real

image

SYNTAX number rms(image)

SYNTAX number image.rms() Image member function

Rotate

SUMMARY Rotates a 2D image clockwise by a given angle

SYNTAX image rotate(image, number angle)

SYNTAX void image.rotate(number angle)

RotateLeft

SUMMARY Rotates an image anti-clockwise an image by 90 deg.

SYNTAX image rotateleft(image, number angle)

SYNTAX void image.rotateleft(number angle)

RotateRight

SUMMARY Rotates an image clockwise an image by 90 deg.

SYNTAX image rotateright(image, number angle)

SYNTAX void image. rotateright(number angle)

RotateX

SUMMARY Rotates a volume image (image3D) clockwise about x

SYNTAX void image3D.rotatex(number angle)

RotateY

SUMMARY Rotates a volume image (image3D) clockwise about y

SYNTAX void image3D.rotatey(number angle)

RotateZ

SUMMARY Rotates a volume image (image3D) clockwise about z

void image3D.rotatez(number angle)

SYNTAX

round

SUMMARY rounds to the nearest integer a real number or a

real image

SYNTAX number round(number)

SYNTAX image round(image)

SYNTAX void image.round() Image member function

Savelmage

SUMMARY Save the image

SYNTAX void SaveImage (image theImage, string fileName [,

number type])

DESCRIPTION Saves the peak data to a given file, as the

specified file type. Default type = current type.
Type = 1 (ascii file), type = 2 (binary) , type = 3

(tiff)

SavePeaks

SUMMARY Save the peaks in a peak list to a file

SYNTAX void SavePeaks(image theImage, string fileName [,

number type])

DESCRIPTION Saves the peak data to a given file, as the

specified file type. Type = 1 (default, text file),

type = 2 - Tempas file

SavePeaksWithDialog

SUMMARY Save the peaks in a peak list to a file after

prompting for filename and location

SYNTAX void SavePeaks(image theImage[, number type])

DESCRIPTION

Saves the peak data to a given file, as the specified file type. Type = 1 (default, text file), type = 2 - Tempas file

SelectAnnotation

SUMMARY Selects an annotation

SYNTAX void SelectAnnotation(Image, Number annotationID)

DESCRIPTION Selects the annotation specified by the annotation

ID in the given image.

Set

SUMMARY Sets the real and imaginary part of a complex number

SYNTAX void complexnumber.set(number x, number y) // complex

number member function

SetAnnotationBackground*

SUMMARY Sets the background of an annotation

SYNTAX void SetAnnotationBackground(Image, Number

annotationID, Number background)

SetAnnotationColor

SUMMARY Sets the RGB Color of the Annotation

SYNTAX void SetAnnotationColor(Image, Number annotationID,

Number red, Number green, Number blue)

SetAnnotationFace*

SUMMARY Sets the text face of an annotation

SYNTAX

Sets the type face of the annotation specified by the annotation ID in the given image.

SetAnnotationFont

SUMMARY Sets the text justification of an annotation

SYNTAX void SetAnnotationJustification(Image, Number

annotationID, Number justification)

DESCRIPTION Sets the justification of the text annotation

specified by the annotation ID in the given image.

SetAnnotationJustification*

SUMMARY Sets the text justification of an annotation

SYNTAX void SetAnnotationJustification(Image, Number

annotationID, Number justification)

SetAnnotationRect

SUMMARY Sets the rect of an annotation

SYNTAX void SetAnnotationRect(Image, Number annotationID,

Number top, Number left, Number bottom, Number right

)

DESCRIPTION Moves the annotation specified by annotation ID in

the given image to the specified coordinates.

SetAnnotationSize

SUMMARY Sets the text size of an annotation

SYNTAX void SetAnnotationSize(Image, Number annotationID,

Number textSize)

DESCRIPTION Sets the size of text of the annotation specified by

the annotation ID in the given image.

SetBlackWhite

Sets the black and white display limits of an image SUMMARY

void image.SetBlackWhite(number black, number SYNTAX

white) // Member function

Sets the limits for what is to be displayed as black DESCRIPTION

and white. Values <= black are all displayed as black. Values >= white are all displayed as white.

SetCalibration

SUMMARY Sets the calibration and possibly calibration unit

of an image

void SetCalibration(image , number calibration) SYNTAX

SYNTAX void SetCalibration(image , number calibration,

number calibrationunit)

The index numbers for the calibration units are: 0 -DESCRIPTION

Pixels, 1 - Å, 2 - nanometer, 3 - 1/Pixels, 4 - 1/Å,

5 - 1/nm

SetCalibrationUnit

SUMMARY Sets the calibration unit of an image

SYNTAX void SetCalibrationUnit(image , number

calibrationunit)

The index numbers for the calibration units are: 0 = DESCRIPTION

Pixels, 1 = Å, 2 = nanometer, 3 = 1/Pixels, 4 = 1/Å,

5 = 1/nm

SetImage

SUMMARY Sets a 2D image at a given position (z) in the

volume image

SYNTAX void image3D.SetImage(image, number

whichposition) // Member function

DESCRIPTION

Copies an existing image into the depth "which position" (0 - (depth-1)) in a volume image

SetDisplayType

SUMMARY Sets the type of display of an image

SYNTAX SetDisplayType(image img, number type)

SetDisplayType(Image, string type) type = "raster","
surface","rgb","line","table","argand","complex".

String is case insensitive

SYNTAX void image.SetDisplayType(number type // Member

function

void image.SetDisplayType(string type) type =
"raster","surface","rgb","line","table","argand","

complex". String is case insensitive

DESCRIPTION types: 1=Raster Image, 2=Surface Plot, 3=RGB, 4
Line Plot, 5-Table, Types 3 is not implemented

SetImageSpace

SUMMARY Sets the space (real/reciprocal) of an image

SYNTAX void image.SetImageSpace(number space) // Member

function

SYNTAX void image3D.SetImageSpace(string space) // Member

function

DESCRIPTION space = 0 Real space , space = 1 Reciprocal Space

space = "real", space = "reciprocal"

SetLimits

SUMMARY Sets the black and white display limits of an image

SYNTAX SetLimits(image, number black, number white)

SYNTAX void image.SetLimits (number black, number white)
// Member function

Equivalent to the member function SetBlackWhite

DESCRIPTION

Sets the limits for what is to be displayed as black and white. Values <= black are all displayed as black. Values >= white are all displayed as white.

SetName

SUMMARY Sets the name of an image

SYNTAX void SetName(image , string)

SYNTAX void image.SetName(string) // Image Member Function

SetPeakList

SUMMARY Associated an image with an existing peaklist.

SYNTAX void SetPeakList(image theImage, image peaklist)

DESCRIPTION After reading in a peaklist from a file or getting

the peaklist from an image, this peaklist can be associated with a desired existing image. The dimensions of the image to be associated the peaklist must be of the same dimensions as the image from which the peaklist originated for this to make

sense.

SetPixel

SUMMARY Sets a specified pixel to a given value

SYNTAX void SetPixel(image , number x, number y, number

val)

SYNTAX void SetPixel(compleximage ,number x, number y,

number val)

SYNTAX void SetPixel(compleximage, number x, number y,

complexnumber val)

SYNTAX void image.SetPixel(number x, number y, number

val) // Member function

SYNTAX void compleximage.SetPixel(number x, number y,

number val) // Member function

SYNTAX void compleximage.SetPixel(number x, number y,

complexnumber val) // Member function

SetPixelAmplitude*

SUMMARY Sets the pixel amplitude for a given pixel in a

complex image

SYNTAX void SetPixelAmplitude(image, number x, number y,

number amplitude)

SYNTAX void image.SetPixelAmplitude(number x, number y,

number amplitude) Image member function

DESCRIPTION

SetPixelPhase

SUMMARY Sets the pixel phase for a given pixel in a complex

image

SYNTAX void SetPixelPhase(image, number x, number y, number

phase)

SYNTAX void image.SetPixelPhase(number x, number y, number

phase) Image member function

DESCRIPTION

SetSelection

SUMMARY Sets the selection rectangle of an image

SYNTAX void SetSelection(Image, Number top, Number left,

Number bottom, Number right)

DESCRIPTION Sets the selection of the given image to the

coordinates.

SetScale

SUMMARY Sets the scale/calibration of an image

SYNTAX void SetScale(image , number scale)

SYNTAX void SetScale(image , number scaleX, number scaleY)

DESCRIPTION

Sets the x and y scale, the number of units per pixel in x and y

SetSurveyMode

SUMMARY Sets the method of survey technique for setting

black and white values

SYNTAX void SetSurveyMode(Image, Number mode)

DESCRIPTION mode = 0 CrossHair . mode = 1 Entire Image,

Equivalent to SetSurveyTechnique

SetSurveyTechnique

SUMMARY Sets the method of survey technique for setting

black and white values

SYNTAX void SetSurveyTechnique(Image, Number mode)

DESCRIPTION mode = 0 CrossHair . mode = 1 Entire Image,

Equivalent to SetSurveyMode

SetVoxel

SUMMARY Sets the voxel value at position (x,y,z)

SYNTAX image3D.SetVoxel(number x, number y, number z,

number value)

SYNTAX compleximage3D.SetVoxel(number x, number y, number

z, complexnumber value)

SetWindowPosition

SUMMARY Sets the window position of an image

SYNTAX void SetWindowPosition(image, number left, number

top)

DESCRIPTION

SetWindowSize

SUMMARY Sets the window size for a displayed image

SYNTAX void SetWindowSize(image, number width, number

height)

Sharpen

SUMMARY Applies a Sharpening Filter to a real image

SYNTAX void Sharpen(image) // In place operation

DESCRIPTION Does a sharpening operation on real image in place

Shift

SUMMARY Shifts the position (0,0) to a new position (sx,sy)

in the image

SYNTAX image Shift(image, number sx, number sy)

SYNTAX void Shift(image) // sx = W/2, sy = H/2 In

place operation

SYNTAX void image.Shift(number sx, number sy)

ShiftAnnotation

SUMMARY Shifts the position of an annotation

SYNTAX void SetAnnotationRect(Image, Number annotationID,

Number shiftX, Number shiftY)

ShiftCenter

SUMMARY Shifts the position (0,0) to the position (W/2,H/2)

in the image

SYNTAX void ShiftCenter(Image) // In place operation

SYNTAX void Image.ShiftCenter() // Member function

DESCRIPTION Shifts each dimension of an image by half. For two

dimensional images it will swap quadrants.

ShiftDown

SUMMARY Returns true/false depending on if the Shift key is

down or not

SYNTAX Boolean ShiftDown(void)

DESCRIPTION Returns 1 if the shift key is down and 0 otherwise.

ShiftImageFocus

SUMMARY Propagates a complex image or wave function by a

distance focus

SYNTAX void ShiftImageFocus(compleximage source, number

focus [, number voltage = 300] [, number sampling =

0.2])

DESCRIPTION The focus variation (or constant) is given in the

image focus. The complex image is propagated over the distance focus. By default the voltage is 300kV.

If the source is calibrated in Angstrom or

nanometer, the sampling is taken from the source.

Otherwise the default is 0.2 $\mbox{\normalfont\AA/pixel}$ and must be set if different.

ShiftOrigin

SUMMARY Shifts the position (0,0) to the position (sx,sy) in

the image

SYNTAX image ShiftOrigin(Image, number sx, number sy)

SYNTAX void ShiftOrigin(Image) // sx = W/2, sy = H/2

(in place)

SYNTAX void image. ShiftOrigin(number sx, number sy)

show

SUMMARY Displays an image. Equivalent to Display

SYNTAX void Show(image)

```
SYNTAX void image.Show() // Member function

SYNTAX void image3D.Show() // Member function

DESCRIPTION Equivalent to Display
```

ShowImage

SUMMARY Displays an image.

SYNTAX void ShowImage(image)

SYNTAX void image.ShowImage() // Member function

DESCRIPTION Equivalent to Display

sgn

SUMMARY Calculates the sign of a real number

SYNTAX RealNumberExpression sgn(RealNumberExpression)

DESCRIPTION Returns 1 if the number is equal or greater than 0

otherwise returns -1

sigma

SUMMARY Calculates the standard deviation of a real image

SYNTAX number sigma(image)

SYNTAX number image.sigma() Image member function

sin

SUMMARY Calculates the sine of a real number or a real image

SYNTAX number sin(number)

SYNTAX image sin(image)

SYNTAX void image.sin() Image member function

sinh

SUMMARY Calculates the hyperbolic sine of a real number or a

real image

SYNTAX number sinh(number)

SYNTAX image sinh(image)

SYNTAX void image.sinh() Image member function

Smooth

SUMMARY Applies a Smoothing Filter to a real image

SYNTAX image Smooth(image)

SYNTAX void image.Smooth() // Member function

Sobel

SUMMARY Applies a Sobel Filter to a real image

SYNTAX image sobel(image)

SYNTAX void image.sobel() // Member function

SpaceDown

SUMMARY Returns true/false depending on if the Space bar is

down or not

SYNTAX Boolean SpaceDown(void)

DESCRIPTION Returns 1 if the space key is down and 0 otherwise.

SphericalBessel $J_n(x)$

SUMMARY Calculates the spherical Bessel J function (first

kind)of order n

SYNTAX number SphericalBesselJ(number n, number x)

DESCRIPTION

SphericalBessel Y_n(x)

SUMMARY Calculates the general Bessel Y function (second

kind) of order n

SYNTAX number SphericalBesselY(number n, number x)

DESCRIPTION

sqrt

SUMMARY Calculates the square root of a real number or a

real image

SYNTAX number sqrt(number)

SYNTAX image sqrt(image)

SYNTAX void image.sqrt() Image member function

sq

SUMMARY Calculates the square of a real number or a real

image

SYNTAX number sq(number)

SYNTAX image sq(image)

SYNTAX void image.sq() Image member function

square

SUMMARY Calculates the square of a real number or a real

image

SYNTAX number square(number)

SYNTAX image square(image)

SYNTAX void image.square() Image member function

stdv

SUMMARY Calculates the standard deviation of a real image

SYNTAX number stdv(image)

SYNTAX number image.stdv() Image member function

sum

SUMMARY Calculates the sum of a real image

SYNTAX number sum(image)

SYNTAX number image.sum() Image member function

tan

SUMMARY Calculates the tangent of a real number or a real

image

SYNTAX number tan(number)

SYNTAX image tan(image)

SYNTAX void image.tan() Image member function

tanh

SUMMARY Calculates the hyperbolic sine of a real number or a

real image

SYNTAX number tanh(number)

SYNTAX image tanh(image)

SYNTAX void image.tanh() Image member function

Templatematch

SUMMARY Returns the position dependent cross-correlation coefficient between an image and a pattern for each

position of the pattern within the image

SYNTAX image TemplateMatch(image sourceImage [. Image

template] [,number normalize])

DESCRIPTION This function performs a cross correlation between

the sourceimage and the template for each possible position of the template within the image. If the sourceImage has a selection, the template needs not be specified as the selection is used as the template. The argument normalize is set to true/false (default = false) to set if the source and template are normalized to zero mean before the cross correlation is taken. Equivalent to

"FindPattern"

TimeBar*

SUMMARY Displays a timebar while evaluating real image

expression

SYNTAX RealImageExpression TimeBar(String title,

RealImageExpression expression)

DESCRIPTION *Not Implemented - Puts up a timebar with the

string as a title for the real expression.

thf

SUMMARY Applies a Threshold Filter to a real image

SYNTAX void image.thf() // Class Member function

DESCRIPTION Equivalent to ThresholdFilter

throw

SUMMARY throws an exception that can be caught by a try

statement

SYNTAX throw(number)

SYNTAX throw(string)

throwstring

SUMMARY throws an exception that can be caught by a try

statement

SYNTAX throwstring(string)

ThresholdFilter

SUMMARY Applies a Threshold Filter to a real image

SYNTAX void image.ThresholdFilter() // Class Member

function

DESCRIPTION

Transpose

SUMMARY Transposes an image

SYNTAX image Transpose(image)

SYNTAX void image.Transpose() // Class Member function

trunc

SUMMARY Truncates a real number to an integer or a real

image to integer values

SYNTAX number trunc(number)

SYNTAX image trunc(image)

SYNTAX void image.trunc() Image member function

TwoButtonDialog

SUMMARY Two button dialog

SYNTAX Boolean TwoButtonDialog(String prompt, String,

rejectLabel, String acceptLabel)

DESCRIPTION Puts up a two button dialog with the accepting and

rejecting buttons labeled according to the

parameters 'acceptLabel' and 'rejectLabel'. Returns true for accept and false for reject.

UniformRandom*

SUMMARY Calculates a random number with uniform distribution

SYNTAX number UniformRandom()

DESCRIPTION

update

SUMMARY Updates an image that has been modified

SYNTAX void image.update() // Image member function

DESCRIPTION To ensure that an image that has been modified gets

its display representation and other statistics

reset

UpdateImage

SUMMARY Updates an image that has been modified

SYNTAX void UpdateImage(image)

DESCRIPTION To ensure that an image that has been modified gets

its display representation and other statistics

reset

ValidAnnotation

SUMMARY Checks if specified annotation exists

SYNTAX Boolean ValidAnnotation(Image, Number

annotationID)

DESCRIPTION Returns true if the annotation specified by the

annotation ID in the given image is valid; returns

false otherwise.

variance

SUMMARY Returns the variance of a real image

SYNTAX number variance(image)

SYNTAX number image.variance() Image member function

Vectorlength

SUMMARY Returns the Length of a real image as a vector

SYNTAX number VectorLength(image)

SYNTAX number image.VectorLength() Image member function

DESCRIPTION Returns the square root of the sum of the squares

VectorMap

SUMMARY Creates a vector map from two images

SYNTAX void VectorMap(image x, image y [, number

samplingX] [, number samplingY] [, number scale])

DESCRIPTION Creates and displays a vector map from two images x

and y which correspond to the x and y components of the vectors. Vectors will be created every samplingX (default=16) pixels and samplingY (default=16) pixels. Vectors are drawn with the magnification

factor: scale (default=10)

VerticalProjection

SUMMARY Returns an image resulting projecting the pixels

(summed) onto the vertical (y) axis

SYNTAX image VerticalProjection(image)

Warp

SUMMARY Calculates bilinear interpolated value within a real

image

SYNTAX image warp(RealImage source, RealImageExpression

sourceX, RealImageExpression sourceY)

DESCRIPTION Transforms the source into a new image based on a

transformation of the x and y values

wf

SUMMARY Returns an image resulting from applying a Wiener

Filter to an image

SYNTAX image wf(image)

SYNTAX void image.wf() // Image Member Function

DESCRIPTION Attempts to reduce random noise in the image of a

crystalline object. Equivalent to "wienerfilter"

width

SUMMARY Returns the width of an image

SYNTAX number image.width() // Image Member Function

SYNTAX number image3D.width() // Image3D Member Function

WienerFilter

SUMMARY Returns an image resulting from applying a Wiener

Filter to an image

SYNTAX image WienerFilter(image)

SYNTAX void image.wienerfilter() // Image Member Function

DESCRIPTION Attempts to reduce random noise in the image of a

crystalline object. Equivalent to "wf"

X

SUMMARY Returns or sets the real part of a complex number

SYNTAX number complexnumber.x() // returns the real part

SYNTAX voi complexnumber.x(number) // sets the real part

y

SUMMARY Returns or sets the imaginary part of a complex

number

SYNTAX number complexnumber.y() // returns the imaginary

part

SYNTAX void complexnumber.y(number) // sets the imaginary

part

Alphabetical description of simulation script functions

Non Member Functions

CalculateAtomicScatteringFactors

SUMMARY Calculates the atomic scattering factors for a given

atomic element and places them in a file

SYNTAX void CalculateAtomicScatteringFactors(number Z [,

number debyeWaller] [, number voltage] [, number

gMax] [, number deltaG])

DESCRIPTION Calculates the full Atomic Scatering Factors for the

element with atomic number Z for all [h,k,l] out to

gMax. Default values are: debyeWaller = 0.5 ,

voltage = 300 kV , gMax = 4.0 1/Å , deltaG - 0.1 1/Å

CalculateExitWave

SUMMARY Calculates the Exit WaveFunction(s) for the current

simulation. Optionally can use a starting wave different from a uniform plane wave of value $\boldsymbol{1}$

everywhere.

SYNTAX void CalculateExitWave ()

CalculateExitWave(ComplexImage entranceWave)

CalculateImage

SUMMARY Calculates the simulated Images(s) for the current

simulation

SYNTAX void CalculateImage()

CalculatePotential

SUMMARY Calculates the 2D Projected Potential(s) for the

current simulation

SYNTAX void CalculatePotential()

PropagateWave

SUMMARY Calculates a 3D complex volume containing the wave

function at each slice for the current simulation up

to a given thickness.

SYNTAX Image3D PropagateWave(number thickness)

DESCRIPTION Implemented as both a standalone function for an

open simulation or as a member function of the class

simulation.

Simulation Class Member Functions

The syntax simulation.functionname() would be used as in the following example Example:

```
simulation sim = getsimulation()
sumber focus = sim.getfocus()
print(focus)
```

Any brackets [] within the functions argument list represents optional arguments which have default values if not specified. If any optional argument needs to be specified, all othe optional arguments preceding it must be specified.

Calculate3DPotential

SUMMARY Calculates the 3D potential for the unit cell of the

current simulation

SYNTAX void simulation.Calculate3Dpotential (image3D

potential)

SYNTAX Image3d potential=simulation.Calculate3Dpotential()

DESCRIPTION Calculates the full 3D potential for the specimen

unit cell out to 2*gmax for all [h,k,l]. Stores the 3D complex potential in the volume image "potential"

which can be displayed using the command

"potential.display()" The volume image is created in

the process.

CalculateExitWave

SUMMARY Calculates the Exit WaveFunction(s) for the current

simulation

SYNTAX void simulation.CalculateExitWave ()

CalculateImage

SUMMARY Calculates the simulated Images(s) for the current

simulation

SYNTAX void simulation.CalculateImage()

CalculatePotential

SUMMARY Calculates the 2D Projected Potential(s) for the

current simulation

SYNTAX void simulation.CalculatePotential()

CreateFrequencyImage

SUMMARY Returns a square image of a simulated object in

reciprocal space

SYNTAX

image simulation.CreateFrequencyImage (image [,
number imageSize] [, number divergenceAngle] [,
number gMax] [, number minIntensity] [, number h,
number k, number l])

DESCRIPTION

Creates and returns a square image of size imageSize*imageSize of the specified image representing the Fourier transform of one of the calculated types in the simulation (potential, exit wave, image) using a sampling given by the value of gMax (sampling = imageSize/(2*gMax)). The minimum intensity in the pattern (the valye of black) is 10**(- minIntensity). Gaussian peaks of sigma given by the divergenceAngle are placed on the diffraction spots. Default values are: imageSize = 512, gMax = gMax for the current simulation, divergenceAngle is the value for the microscope for the simulation. MinIntensity = 6. The optional values h,k,l are the indicies of the desired reflection along the positive x-axis in the diffraction pattern image.

CreateImage

SUMMARY

Returns a square image from a given calculated image of given size and sampling

SYNTAX

image simulation.CreateImage(image [, number imageSize] [, number sampling])

DESCRIPTION

Creates and returns a square image of size imageSize*imageSize of the specified image
representing one of the calculated types in the
simulation (potential, exit wave, image) using a
sampling of sampling. Default values are: whichImage
= 1 , imageSize = 512 , sampling = 0.1Å

DisplayExitWave

SUMMARY

Displays a calculated exit wave

SYNTAX

void simulation.DisplayExitWave([number
whichExitWave] [, number nX] [, number nY] [,
number zoom])

DESCRIPTION

Creates and displays the specified exit wave for nX by nY unit cells, using a zoom factor. The image will be resampled to make dx and dy the same and to make the angle 90 degrees if necessary. Defaults are: whichExitWave = 1, nX = 1, nY = 1, zoom = 1

DisplayExitWaveModulus

SUMMARY Displays the modulus of a calculated exit wave

SYNTAX void simulation.DisplayExitWaveModulus([number whichExitWave][, number nX][, number nY][,

number zoom])

DESCRIPTION Creates and displays the modulus of the specified

exit wave for nX by nY unit cells, using a zoom factor. The image will be resampled to make dx and dy the same and to make the angle 90 degrees if necessary. Defaults are: whichExitWave = 1, nX = 1,

nY = 1, zoom = 1

DisplayExitWavePhase

SUMMARY Displays the phase of a calculated exit wave

SYNTAX void simulation.DisplayExitWavePhase([number whichExitWave] [, number nX] [, number nY] [,

number zoom])

DESCRIPTION Creates and displays the phase of the specified exit

wave for nX by nY unit cells, using a zoom factor. The image will be resampled to make dx and dy the same and to make the angle 90 degrees if necessary. Defaults are: whichExitWave = 1, nX = 1, nY = 1,

zoom = 1

DisplayImage

SUMMARY Displays a calculated image

SYNTAX void simulation.DisplayImage([number whichImage] [, number nX] [, number nY] [, number zoom])

DESCRIPTION Creates and displays the specified image for nX by

nY unit cells, using a zoom factor. The image will be resampled to make dx and dy the same and to make the angle 90 degrees if necessary. Defaults are:

whichImage = 1, nX = 1, nY = 1, zoom = 1

DisplayPotential

SUMMARY Displays a calculated 2D projected potential

SYNTAX void simulation.DisplayPotential([number

whichPotential] [, number nX] [, number nY] [,

number zoom])

DESCRIPTION Creates and displays the specified exit wave for nX

by nY unit cells, using a zoom factor. The image will be resampled to make dx and dy the same and to make the angle 90 degrees if necessary. Defaults are: whichPotential = 1, nX = 1, nY = 1, zoom = 1

Focus

SUMMARY Sets the focus of the simulation

SYNTAX void simulation. Focus (number focus)

DESCRIPTION Sets the focus [Å] for the current simulation

GetAperture

SUMMARY Returns the radius of the outer objective lens

aperture (1/Ă)

SYNTAX number simulation.GetAperture()

DESCRIPTION Equivalent to GetOuterAperture

GetApertureAngle

SUMMARY Returns the angle of the outer objective lens

aperture (mrad)

SYNTAX number simulation.GetApertureAngle()

GetApertureCenter

SUMMARY Returns the center of the objective lens aperture in

"tilt" angle (mrad) and azimuthal angle (degrees)

SYNTAX number simulation.GetApertureCenter(number theta,

number phi)

GetApertureCenterHK

SUMMARY Returns the center of the objective lens aperture in

(H,K) of the reciprocal space of the unit cell

SYNTAX void simulation.GetApertureCenterHK(number cH,

number cK)

GetCs

SUMMARY Returns the Spherical Aberration Cs in mm le of the

outer objective lens aperture (mrad)

SYNTAX number simulation.GetCs()

GetCs5

SUMMARY Returns the 5th order Spherical Aberration Cs5 in mm

SYNTAX number simulation.GetCs5()

GetDeltaFocus

SUMMARY Returns the increment in focus [Å] for a simulation

of a thru-focus series

SYNTAX number simulation.GetDeltaFocus()

GetDeltaThickness

SUMMARY Returns the increment in thickness [Å] for a thru-

thickness calculation

SYNTAX number simulation.GetDeltaThickness()

GetDivergence

SUMMARY Returns the convergence angle (mrad) for the

calculation

GetEndFocus

SUMMARY Returns the last focus [Å] for a simulation of a

thru-focus series

SYNTAX number simulation.GetEndFocus()

GetEndThickness

SUMMARY Returns the last thickness [Å] for a thru-thickness

calculation

SYNTAX number simulation.GetEndThickness()

GetExitWave

SUMMARY Returns an image containing the exit wave of the

calculation

SYNTAX image simulation.GetExitWave([number whichExitWave]

[, number nX] [, number nY] [, number zoom])

DESCRIPTION Creates and returns an image of the specified exit

wave for nX by nY unit cells, using a zoom factor,
Defaults are: whichExitWave = 1, nX = 1, nY = 1,

zoom = 1

GetExitWaveModulus

SUMMARY Returns an image containing the modulus of the exit

wave

SYNTAX image simulation.GetExitWaveModulus([number

whichExitWave] [, number nX] [, number nY] [,

number zoom])

DESCRIPTION Creates and returns an image of the specified exit

wave modulus for nX by nY unit cells, using a zoom
factor, Defaults are: whichExitWave = 1, nX = 1, nY

= 1, zoom = 1

GetExitWavePhase

SUMMARY Returns an image containing the phase of the exit

wave

SYNTAX image simulation.GetExitWavePhase([number

whichExitWave])

DESCRIPTION Creates and returns an image of the specified exit

wave phase for nX by nY unit cells, using a zoom factor, Defaults are: whichExitWave = 1, nX = 1, nY

= 1, zoom = 1

GetFocus

SUMMARY Returns the focus [Å] for the simulation

SYNTAX number simulation.GetFocus()

GetFocusSpread

SUMMARY Returns the focus [Å] for the simulation

SYNTAX number simulation.GetFocusSpread()

DESCRIPTION The focus spread refers to the effect of the

chromatic aberration of the objective lens and contributes to the damping of the contrast transfer

function

Getlmage

SUMMARY Returns an image containing the calculated simulated image

SYNTAX image simulation.GetImage([number whichImage] [, number nX] [, number nY] [, number zoom])

DESCRIPTION Creates and returns an image of the specified

simulated image for nX by nY unit cells, using a zoom factor, Defaults are: whichImage = 1, nX = 1,

nY = 1, zoom = 1

GetInnerAperture

SUMMARY Returns the inner radius of the objective lens

aperture (1/Å)

SYNTAX number simulation.GetInnerAperture()

GetOpticAxis

SUMMARY Returns the center of the optic axis in tilt angle

(mrad) and azimuthal angle (degrees)

SYNTAX number simulation.GetApertureCenter(number theta,

number phi)

GetOpticAxisHK

SUMMARY Returns the center of the optic axis in (H,K) of the

reciprocal space of the unit cell

SYNTAX void simulation.GetOpticAxisHK(number cH, number

cK)

GetOuterAperture

SUMMARY Returns the radius of the outer objective lens

aperture (1/Å)

SYNTAX number simulation.GetOuterAperture()

DESCRIPTION Equivalent to GetAperture

GetPhaseShift

SUMMARY Returns the phase shift for the phase plate in units

of π

SYNTAX number simulation.GetPhaseShift()

GetPhaseShiftRadius

SUMMARY Returns the radius for the phase plate in units of

1/Ă

SYNTAX number simulation.GetPhaseShiftRadius()

GetPhaseShiftRadius2

SUMMARY Returns the outer radius for the phase plate in

units of 1/Å

SYNTAX number simulation.GetPhaseShiftRadius2()

GetPotential

SUMMARY Returns an image containing the calculated 2D

projected potential

SYNTAX image simulation.GetPotential([number

whichPotential] [, number nX] [, number nY] [,

number zoom])

DESCRIPTION Creates and returns an image of the specified

potential for nX by nY unit cells, using a zoom
factor, Defaults are: whichPotential = 1, nX = 1, nY

= 1, zoom = 1

GetStartFocus

SUMMARY Returns the starting focus (Å) for a thru-focus

series

SYNTAX number simulation.GetStartFocus()

GetStartThickness

SUMMARY Returns the starting thickness (Å) for a thru-

thickness series

SYNTAX number simulation.GetStartThickness()

GetThickness

SUMMARY Returns the thickness (Å) for the simulation

SYNTAX number simulation.GetThickness()

GetTilt

SUMMARY Returns the tilt angle of the specimen in mrad and

the azimuthal angle of specimen tilt with respect to

the horizontal axis in degrees

SYNTAX void simulation.GetTilt(number theta, number phi)

GetTiltAngle

SUMMARY Returns the tilt angle of the specimen in mrad

SYNTAX number simulation.GetTiltAngle()

GetTiltDirection

SUMMARY Returns the azimuthal angle of specimen tilt with

respect to the horizontal axis in degrees

SYNTAX number simulation.GetTiltDirection()

GetTiltH

SUMMARY Gets the h value of the center of laue circle

(specimen tilt)

SYNTAX number simulation. GetTiltH()

GetTiltHK

SUMMARY Returns the center of Laue circle in (H,K) of the

reciprocal space of the unit cell

SYNTAX void simulation.GetTiltHK(number cH, number cK)

GetTiltK

SUMMARY Gets the k value of the center of laue circle

(specimen tilt)

SYNTAX number simulation.GetTiltK()

GetVibration

SUMMARY Gets the vibration of the "specimen" along x and y

SYNTAX void simulation.GetVibration(number variable vX,

numberVariable vY)

GetVibrationX

SUMMARY Gets the vibration of the "specimen" along x

SYNTAX number simulation.GetVibrationX()

GetVibrationY

SUMMARY Gets the vibration of the "specimen" along y

SYNTAX number simulation.GetVibrationY()

GetVoltage

SUMMARY Returns the voltage of the microscope for the

simulation (kV)

SYNTAX number simulation.GetVoltage()

LoadExitWave

SUMMARY Returns an image containing the exit wave of the

calculation

SYNTAX image simulation.LoadExitWave([number

whichExitWave])

DESCRIPTION

Returns the specified exit wave as an image. Default value for which exit wave if not specified is 1. The image will have the sampling of the simulation and the angle of the unit cell.

LoadExitWaveModulus

SUMMARY Returns an image containing the modulus of the exit

SYNTAX image simulation.LoadExitWaveModulus([number

whichExitWave])

DESCRIPTION Returns the specified exit wave modulus as an image.

Default value for which exit wave if not specified is 1. The image will have the sampling of the simulation and the angle of the unit cell.

LoadExitWavePhase

SUMMARY Returns an image containing the phase of the exit

wave

image simulation.LoadExitWavePhase([number SYNTAX

whichExitWave])

Returns the specified exit wave phase. Default value DESCRIPTION

for which exit wave if not specified is 1. The exit wave phase image will have the sampling of the simulation and the angle of the unit cell.

LoadImage

SUMMARY Returns an image containing the calculated simulated

image

SYNTAX image simulation.LoadImage([number whichImage])

DESCRIPTION Returns the specified image. Default value for which image if not specified is 1. The image will have the

sampling of the simulation and the angle of the unit cell.

LoadPotential

SUMMARY Returns an image containing the calculated 2D

projected potential

SYNTAX image simulation.LoadPotential([number

whichPotential])

DESCRIPTION Returns the specified potential as an image. Default

value for which potential if not specified is 1. The image will have the sampling of the simulation and

the angle of the unit cell.

PropagateWave

SUMMARY Calculates a 3D complex volume containing the wave

function at each slice for the current simulation up

to a given thickness.

SYNTAX Image3D simulation.PropagateWave(number thickness)

DESCRIPTION Returns a 3D complex volume containing the wave

function up to a given thickness. In order to see the wave, the volume image must be displayed in the

script, such as Image3D wave =

simulation.PropagateWave(200); wave.show();

SetAperture

SUMMARY Sets the outer objective lens aperture (1/Å)

SYNTAX void simulation.SetAperture(number)

SetApertureAngle

SUMMARY Sets the outer objective lens aperture in mradians

SYNTAX void simulation.SetApertureAngle(number)

SetApertureCenter

SUMMARY Sets the center of the objective lens aperture

SYNTAX

void simulation.SetApertureCenter(number theta,
number phi)

SetApertureHK

SUMMARY

Sets the center of the objective lens aperture in (H,K) of the reciprocal space of the unit cell

SYNTAX

void simulation.SetApertureHK(number cH, Number cK)

SetCs

SUMMARY

Sets the Spherical Aberration Cs in $\ensuremath{\mathsf{mm}}$

SYNTAX

void simulation.SetCs(number)

SetCs5

SUMMARY

Sets the $5\ensuremath{^{\text{th}}}$ order Spherical Aberration Cs5 in mm

SYNTAX

void simulation.SetCs5(number)

SetDeltaFocus

SUMMARY

Sets the Incremental focus (Å) for a thru-focus series

SYNTAX

void simulation.SetDeltaFocus(number)

SetDeltaThickness

SUMMARY

Sets the incremental thickness (Å) for a thruthickness series

SYNTAX

void simulation.SetDeltaThickness(number)

SetDivergence

SUMMARY

Sets the convergence angle (mrad) for the calculation

SYNTAX void simulation.SetDivergence(number)

SetEndFocus

Sets the ending value for focus [Å] in a thru-focus SUMMARY

series

void simulation.SetEndFocus(number) SYNTAX

SetEndThickness

Sets the ending value for thickness [Å] in a thru-SUMMARY

thickness series

SYNTAX void simulation.SetEndFocus(number)

SetFocus

Sets the focus (Å) for the calculation SUMMARY

SYNTAX void simulation.SetFocus(number)

SetFocusSpread

Sets the focus Spread (Å) associated with the SUMMARY

chromatic aberration of the objective lens for the

calculation

SYNTAX void simulation.SetFocusSpread(number)

SetInnerAperture

Sets the inner objective lens aperture (1/Å) SUMMARY

SYNTAX void simulation.SetInnerAperture(number)

SetOpticAxis

SUMMARY Sets the center of the optic axis in tilt angle

(mrad) and azimuthal angle (degrees)

SYNTAX

void simulation.SetOpticAxis(number theta , number
phi)

SetOpticAxisHK

SUMMARY

Sets the center of the optic axis in (H,K) of the reciprocal space of the unit cell real

SYNTAX

void simulation.SetOpticAxisHK(number cH, number cK)

SetOuterAperture

SUMMARY

Sets the outer objective lens aperture (1/Å)

SYNTAX

void simulation.SetOuterAperture(number)

SetPhaseShift

SUMMARY

Sets the phase shift for the phase plate in units of $\boldsymbol{\pi}$

SYNTAX

void simulation.SetPhaseShift(number)

SetPhaseShiftRadius

SUMMARY

Sets the radius for the phase plate in units of $1/\mbox{\normalfont\AA}$

void simulation.SetPhaseShiftRadius(number)

 ${\tt SYNTAX}$

SetPhaseShiftRadius2

SUMMARY

Sets the outer radius for the phase plate in units of $1/\mbox{\normalfont\AA}$

SYNTAX

void simulation.SetPhaseShiftRadius(number)

DESCRIPTION

If the second radius is set greater than the PhaseShiftRadius, the beams are blocked between PhaseShiftRadius and PhaseShiftRadius2

SetStartFocus

SUMMARY Sets the starting focus (\mathring{A}) for a thru-focus series

SYNTAX void simulation.SetStartFocus(number)

SetStartThickness

SUMMARY Sets the starting thickness for a thru-thickness

series

SYNTAX void simulation.SetStartThickness(number)

SetThickness

SUMMARY Sets the thickness (Å) for the calculation

SYNTAX void simulation.SetThickness(number)

SetTiltAngle

SUMMARY Sets the tilt angle of the specimen in mrad

SYNTAX void simulation.SetTiltAngle(number)

SetTiltDirection

SUMMARY Sets the azimuthal angle of specimen tilt with

respect to the horizontal axis in degrees

SYNTAX void simulation.SetTiltDirection(number)

SetTiltH

SUMMARY Sets the h value of the center of laue circle

(specimen tilt)

SYNTAX void simulation.SetTiltH(number)

SetTiltHK

SUMMARY Sets the h,k values of the center of laue circle

(specimen tilt)

SYNTAX void simulation.SetTiltHK(number h, number k)

SetTiltK

SUMMARY Sets the k value of the center of laue circle

(specimen tilt)

SYNTAX void simulation.SetTiltK(number)

SetVibration

SUMMARY Sets the vibration of the "specimen" along x and y

SYNTAX void simulation.SetVibration(number vibX, number

vibY)

SetVibrationX

SUMMARY Sets the vibration of the "specimen" along x

SYNTAX void simulation.SetVibrationX(number)

SetVibrationY

SUMMARY Sets the vibration of the "specimen" along y

SYNTAX void simulation.SetVibrationY(number)

SetVoltage

SUMMARY Sets the voltage of the microscope for the

simulation (kV)

SYNTAX void simulation.SetVoltage(number)

ShowExitWave

Displays a calculated exit wave SUMMARY

SYNTAX void simulation.ShowExitWave([number whichExitWave] [, number nX] [, number nY] [, number zoom])

DESCRIPTION Creates and displays the specified exit wave for nX

by nY unit cells, using a zoom factor, Defaults are:

whichExitWave = 1, nX = 1, nY = 1, zoom = 1

ShowExitWaveModulus

SUMMARY Displays the modulus of a calculated exit wave

void simulation.ShowExitWaveModulus([number SYNTAX

whichExitWave] [, number nX] [, number nY] [,

number zoom])

DESCRIPTION Creates and displays the modulus of the specified

> exit wave for nX by nY unit cells, using a zoom factor, Defaults are: whichExitWave = 1, nX = 1, nY

= 1, zoom = 1

ShowExitWavePhase

SUMMARY Displays the phase of a calculated exit wave

SYNTAX void simulation.ShowExitWavePhase([number

whichExitWave] [, number nX] [, number nY] [,

number zoom])

Creates and displays the phase of the specified exit DESCRIPTION

wave for nX by nY unit cells, using a zoom factor, Defaults are: whichExitWave = 1, nX = 1, nY = 1,

zoom = 1

ShowImage

SUMMARY Displays a calculated image

SYNTAX void simulation.ShowImage([number whichImage] [, number nX] [, number nY] [, number zoom])

Creates and displays the specified image for nX by DESCRIPTION

nY unit cells, using a zoom factor, Defaults are: whichImage = 1, nX = 1, nY = 1, zoom = 1

ShowPotential

```
SUMMARY
                          Displays a calculated 2D projected potential
SYNTAX
                          void simulation.ShowPotential( [number
                          whichPotential ] [, number nX ] [, number nY ] [,
                          number zoom ] )
                          Creates and displays the specified exit wave for nX
DESCRIPTION
                          by nY unit cells, using a zoom factor, Defaults are:
                          whichPotential = 1, nX = 1, nY = 1, zoom = 1
       Example:
               // Precession Tilt series
               // This is summing over the power-spectrum of the exit wave function
               // by spinning the beam in a circle. The beam tilt is theta (30 mrad).
               // The increment in the azimuthal angle is dphi (6 degrees)
               // A table of HKL values for different thicknesses is shown
               // For illustration purposes, a precession image is also calculated
               number theta = 30
                                                // The tilt angle in mrad
               number phi = 0
                                                // Tilt angle (degrees) with respect to a-axis
               number dphi = 6
                                                // increments in tilt angle (degrees)
               simulation sim = getsimulation()
                                                // Get the simulation
               // We are making sure that everything has been calculated and is current
               sim.calculateall()
                                                // Declare and load the exit wave
               image xw = sim.loadexitwave()
               image im = sim. loadimage()
                                                // Declare and load the image
                                                // Declare the sum for the images and zero
               image sumim = im ; sumim = 0 ;
               image sumps = xw; sumps = 0;
                                                // Declare the sum for the powerspectrum
                                                // and zero
               OpenResultsWindow()
               for(number thickness = 10; thickness <= 100; thickness += 10) {
                    sim.setthickness(thickness)
                                                        // declare and initialize our counter
                    number i = 0
```

for(phi = 0; phi < 360; phi += dphi) { // loop over the azimuthal angle

// set the tilt of the specimen

sim.settilt(theta,phi)

```
// this is equivalent to the tilting the beam
          sim.calculateexitwave()
                                            // Calculate the new exit wave
          sim.calculateimage()
                                            // Calculate the new image
          sumim += sim. loadimage()
                                            // Add the image to the sum
          xw = sim. loadexitwave()
                                            // Load the exit wave
         xw.fft()
                                            // Fourier transform to get the frequency
                                            // complex coefficients
         xw *= conjugate(xw)
                                            // Set the complex PowerSpectrum
                                            // If we had used xw.ps() to get the
                                            // power spectrum we would have had a real
                                            // image in "real" space
                                            // Add the powerspectrum to the sum
         sumps += xw
         i++
                                            // Keep track of the count
         print("phi = "+phi)
                                            // Just to know where we are in the loop
     }
     sumim /= i
                                            // Divide by the number of terms in the sum
     // Create a rectangular image of size 1024 by 1024 of sampling 0.1 Å (default)
     image precessionImage = sim.createimage(sumim,1024)
     precessionImage.setname("Image Precession")
     precessionImage.show()
                                            // Show the summed images
     sumps /= i
                                            // Divide by the number of terms in the sum
     sumps.sqrt()
                                            // To compare with the Scattering factors
     // Create a rectangular image of size 1024 by 1024 out to gMax = 4 \frac{1}{A}
     // with a convergence angle of 0.2 mrad
     image precessionPS = sim.createfrequencyimage(sumps,1024,0.2,4)
     precessionPS.setname("Power Spectrum Precession Thickness "+ sim.getthickness())
     precessionPS.show()
                                            // Show the summed power spectrum
     sumps.setname("thickness" + sim.getthickness())
     sim.createhkltable(sumps)
}
```